

KODAK KODACOLOR DTF FILM (DARK SHIRT)

TO CREATE A PRESET IN EPSON GARMENT CREATOR FOR
KODAK KODACOLOR DTF FILM USE THESE SETTINGS

START BY SELECTING THE DEFAULT PRESET FOR:
DARK COLOR T SHIRT (STANDARD)

THEN MAKE THE FOLLOWING SETTING CHANGES:

PRINT QUALITY: CUSTOMIZE

UNCHECK DOUBLE PASS

WHITE PRINT QUALITY: LEVEL 1

COLOR PRINT QUALITY: LEVEL 3

PRINT DIRECTION: UNI-DIRECTION

INTENSITY (COLOR): -15

INTENSITY (WHITE): 0

REDUCE WHITE AREA: 3

INK ORDER: REVERSE
(COLOR > WHITE)

CLICK THE + SIGN IN THE BOTTOM RIGHT CORNER TO
NAME AND SAVE THE PRESET

