

# **Bulb Changer Kit Instructions**

Product No. 48450/48350


#### Please read the following before use:

- 1. Make sure all electrical power to the light bulbs are off before changing any light bulbs.
- 2. Please select the right tool attachments below that best fits the light bulb size and condition.
- 3. Adjust a suitable height for the extension pole for ease of use.



#### How to use Broken Bulb Extractor:

- 1. Attach Extractor Pole Adaptor to Extension Pole
- Determine the size of the Broken Bulb Extractor to use for the broken light bulb (Large or Small).
- Attach Small Broken Bulb Extractor to Extractor
  Pole Adpater. If you decided to use the Small
  Broken Bulb Extractor, stop, then proceed to Step 4.
  If you need to use the Large Broken Bulb Extractor,
  attach it over the Small Broken Bulb Extractor.
- 4. Place the tip of the Broken Bulb Extractor to the broken bulb's glass filament. Push upward and turn counter-clockwise. Then unscrew the broken light bulb from the socket of the light fixture.



### How to use Floodlight and Standard Bulb/CFL Changers:

- 1. Determine the Bulb Changer size to use for the light bulb.
- Slide the Bulb Changer onto the light bulb. Turn the pole counter-clockwise to loosen the bulb, then remove.
- Place a new light bulb in the bulb changer, then place it into the light fixture's socket. Turn the pole clockwise to tighten the new bulb.

## **How to use Recessed Floodlight Suction Cup Attachment:**

- 1. First, attach the long string that is included in the bulb changer kit.
- 2. Thread the string through the base of the suction cup, then tie it to the ear of the suction cup. Leave the excess string hanging, while working through the next steps. (String should be longer than the extension pole when it's fully extended. Do not cut the string.) The suction cup's position is readjustable by pulling the string to release it, and repositioning it to the desired postion.
- 3. Push the suction cup onto the center of the light bulb, then turn the extension pole clockwise to loosen the light bulb.

