

## Description

With every tent, there will be 3 x WaterGates included which slip onto each of the 3 D-Rings before attaching the ratchets. These WaterGates will stop the ingress of rain water in event of sustained rain fall. As the straps get soaked, water can travel towards the tent and use the strap as a conduit, allowing this rainwater to slip under the rain cover. Some of this water can run around the D-Ring and saok into the webbing tent structure.

Use these WaterGate to ensure that water will never reach the tent and ensure everything under the rain cover to remain bone dry.







