



Aquanaut Extreme

Ultra Low Profile CPU + Pump Water Block




Clean parts with mild soap water before assembly



STOP tightening screw when surfaces of the parts touch

1

O-rings (x3) + lower block + screws (x4)



2

O-ring + bracket + cold plate + screws (x4)

