



Quick Guide ADC Pro





Remarks:

- 1) This diagram illustrates the operation flow among the different functional displays only, the display numbers in this diagram may NOT comply to fact.
- 2) Press the [set] * button to select the setting by backward scrolling or [reset] button to select the setting by forward* scrolling during the above setting displays**.
- 3) Exiting the 'YES' display during the above setting sequences, the setting will be executed. Such as exiting the 'YES' display during reset maximum wind speed setting sequences, the maximum wind speed will be reset to the current wind speed.
- 4) Exiting the 'ON' display during the above setting sequences, the corresponding function will be turn on. Such as exiting the 'ON' display during the wind speed alarm setting sequences, the wind speed alarm will be turn ON.