





**COZY**MATIC




## ASSEMBLY INSTRUCTIONS

Emerson Solid Wood End Table

## Check the components before assembly



■ Desktop × 1




■ Underside × 1




■ Support × 2


### ■ Hardware




For any issue related to the product,  
please contact [wecare@cozymatic.com](mailto:wecare@cozymatic.com).




Step 1: Install the underside.



Step 2: Install the desktop



Step 3: Install the wheels.



Step 4: Flip the table over.