

BIOENNO POWER MOBILE TRANSCEIVER COMPATIBILITY GUIDE: *ELECRAFT, KENWOOD, FLEX RADIO, POWERWERX*

ELECRAFT	Transmit (WATTS)	Transmit (AMPS)	Receive (AMP)	Compatible Models (*For runtime benchmarks, please consult 2080 and 5050 Duty Charts)
KX2	10/8 (Variable)	1-3 (Variable)	0.135 Standby	BLF-1203W/A/AB, BLF-12045W, BLF-1206A, BLF-1209A/AS, BLF-1212A/AS, BLF-1215A/AS
KX3	0.1-10	1-2+ (Variable)	0.150 Standby	BLF-1203W/A/AB, BLF-12045W, BLF-1206A, BLF-1209A/AS, BLF-1212A/AS, BLF-1215A/AS
K3S	0.1-100	17-22 (Variable)	3-4 (Variable)	BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS, BLF-1230A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS

KENWOOD	Transmit (WATTS)	Transmit (AMPS)	Receive (AMP)	Compatible Models (*For runtime benchmarks, please consult 2080 and 5050 Duty Charts)
TM-D710GA	50/10/5	13-4 (Mode Variable)	<1.2 (2W Audio)	BLF-1209A/AS, BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS
TM-V71A	50/10/5	13-4 (Mode Variable)	<1.2 (2W Audio)	BLF-1209A/AS, BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS
TM-281A	65/25	14,8	<1	BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS, BLF-1230A/AS
TS-480HX	200/100 (Variable)	20.5	<1.5 (Standby)	BLF-1220A/AS/ BLF-1230A/AS, BLF-1240A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS, BLF-12150AS, BLF-12200AS, BLF-12300AS
TS-480SAT	200/100 (Variable)	20.5	<1.5 (Standby)	BLF-1220A/AS/ BLF-1230A/AS, BLF-1240A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS, BLF-12150AS, BLF-12200AS, BLF-12300AS
TS-2000	100/50/10	20.5,18,9	2.6 (Standby)	BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS, BLF-1230A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS
TS-2000X	100/50/10	20.5,18,9	2.6 (Standby)	BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS, BLF-1230A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS

FLEX RADIO	Transmit (WATTS)	Transmit (AMPS)	Receive (AMP)	Compatible Models (*For runtime benchmarks, please consult 2080 and 5050 Duty Charts)
FLEX-6300	1-100	23	1.7	BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS, BLF-1230A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS
FLEX-6400	1-100	23	1.7	BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS, BLF-1230A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS
FLEX-6500	1-100	23	1.7	BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS, BLF-1230A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS
FLEX-6600	1-100	23	2	BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS, BLF-1230A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS
FLEX-6700	1-100	23	3	BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS, BLF-1230A/AS, BLF-1250A/AS, BLF-1260AS/L, BLF-12100AS

POWERWERX	Transmit (WATTS)	Transmit (AMPS)	Receive (AMP)	Compatible Models (*For runtime benchmarks, please consult 2080 and 5050 Duty Charts)
DB-750X	50-5 (Mode Variable)	N/A	N/A	BLF-1209A/AS, BLF-1212A/AS, BLF-1215A/AS, BLF-1220A/AS

*All transmit and receive figures represented are as listed by their respective manufacturers for current production mobile radio transceivers, handheld units and basecamp units are not represented. Bioenno Power bases the recommendations for compatible battery models herein based on average benchmark figures across multiple models using standard duty cycle representations, actual performance and usage may vary in accordance to how an individual radio transceiver is set up.