
AIRCYCLER® WIRING for adding a booster fan

USING A FANCONNCT SWITCH





Booster fan will come on anytime damper is open.

C - Common W - Heating Gt - Fan From Thermostat Gf - Fan To Furnace V - Vent Ex - Exhaust Fan

Vnc - Normal Closed Vent

dampers that are normally open)

(To power spring-return

KEY

R - 24VAC Power