
AIRCYCLER® WIRING for adding a booster fan USING A FANCONNECT SWITCH





Booster fan will come on anytime damper is open.

R - 24VAC Power C - Common W = Heating Gt - Fan From Thermostat Gf - Fan To Furnace V - Vent Ex - Exhaust Fan Vnc - Normal Closed Vent (To power spring-return dampers that are normally open)