FIX-R All Weather Roof Coat 001

ALL WEATHER ROOF COAT



Rejuvenates your roof.

Seamless waterproof coating to prolong the life of flat roofs.

Description

FIX-R All Weather Roof Coat is a flexible, bituminous coating containing reinforcing fibres and designed for easy application to protect and prolong the life of existing roofing systems.

The ideal solution for protecting and rejuvenating your roof.

Directions for use

All surfaces must be clean, dry and free from grease, oil, dirt and loose material. Destroy any moss or lichen growth with a proprietary fungicidal wash, and prime the surface being treated with FIX-R Quick Dry Bitumen Primer and allow to dry. Metal surfaces, where necessary, should be prepared with a wire brush.

Prime iron and steel with suitable rust inhibitive primer, and allow to dry thoroughly. Any blisters and cracks present in the existing roof surface should be repaired using a Universal Roof Repair Compound.

Application

Stir FIX-R All Weather Roof Coat thoroughly and then apply an even coating using a brush at a rate of $2.5 \text{ m}^2/\text{Litre}$. Allow product to dry thoroughly (approximately 24 hours) and then apply a second coat at right angles to the first at a rate of $2.5 \text{ m}^2/\text{Litre}$. For additional ultraviolet protection, slate flakes or chippings can be immediately sprinkled onto the top coat whilst still wet.

Coverage

2.5m²/litre per coat

Cleaning

White spirit

Packaging

5L & 25L

Storage

Containers should be kept sealed in a cool, dry, well ventilated environment and all practical precautions taken against fire. Partly used containers may be resealed and used again after correct storage. To avoid the risk of spillage, always store and transport in a secure upright position.

Shelf Life

Maximum 3 years in sealed container.

Health & Safety

Keep away from sources of ignition, including pilot lights and sparks. No smoking. Avoid contact with skin by careful working and use of gloves. In case of contact with skin wash immediately with soap or a recognised skin cleanser. Do not use solvents to clean the skin. Use only in well ventilated areas. When using, do not eat, drink or smoke.

Do not empty into drains. Remove excess material from tools before cleaning. Some local authorities have special facilities for the disposal of waste liquids. Remove lid and allow residue to dry in a safe place prior to disposal of empty containers. A separate safety datasheet is available on request to FIX-R.

Fire

In case of fire use foam, dry powder or CO₂ extinguisher, sand or earth. Never use water.





Date of issue: Mar 19