

Assembly Instructions





HARDWARE


Α	В	С	D	E
<u> </u>	() 111111111111111111111111111111111111			⊕
M6X90 46pcs	M6X60 4pcs	M6 48pcs	φ8X30 50pcs	M4. 2X40 1pcs
F	G	Н		J
	<u>⊚_1111111111</u> >>	<u> </u>	(DI)))))))))	<u>⊚</u>
M6X18 2pcs	M4X30 60pcs	M6X50 12pcs	M6X10 2pcs	M3X15 4pcs
K	L	M	N	0
	⊛ >			
2pcs	M4X35 2pcs	M6X12 2pcs	4pcs	2pcs











RETURN / DAMAGE CLAIM INSTRUCTIONS

1. **DO NOT** discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: sales@tsbliving.co.nz

Christchurch Branch: customersupport@tsbliving.co.nz

Wellington Branch: wellington@tsbliving.co.nz