

Thank you for buying our safety playpen for children's games.
 Please read and follow our instruction manual carefully.
 The correct method of use and precautions should be followed.

Feature

- Unique joint insertion type assembled children's playpen, not easy to be pushed by the baby.
- Free to add the number of playpen pieces, and combined into a variety of different shapes.
- Fence with toys can make baby to play happily.

Example



toy fence



side fence1





side fence2



door fence

Combination



- ⚠ The joint Angle of the fence can be installed at 180° 150° 120° 90°.
- ⚠ Fence assembly should be careful not to pinch fingers.

There are two knobs on the connecting piece on the top of the small piece of fence. Turn the knobs to the left 90° to lock the connection, and turn 90° to the right to loosen the connection.



Push this button gently to the right to open the door. Push this button gently to the left to close the door.

Product Information

Production	Fruit Playpen
Model	BBPP-B2-8P-PKWH
	BBPP-B2-8P-GNWH
Material	HDPE
For age	over 6 months

Operating Instruction

This manual records the precautions for safe use. Be sure to read it carefully and keep it properly.

Note for safe use:

In order to avoid the occurrence of serious injury accident, the following precautions should be strictly observed. The object of use is children over 6 months old

- 1、 Children must play within sight of adults, and adults must pay special attention to their behavior.
- 2、 Please place it in a flat and safe place (do not place it on the quilt).
- 3、 Avoid pinching fingers when assembling
- 4、 Do not ride or lean on merchandise
- 5、 Be careful not to let child's hands or feet reach into doors or gaps in plates, which may lead to injuries.
- 6、 Plates are to be disassembled to assemble or change Angle. When plates cannot be disassembled to join or change Angle, splicing or connecting parts may be broken.
- 7、 Do not go near fire, heating or hot water. This product may be out of shape
- 8、 Do not let the child eat the parts, screws and so on by mistake.
- 9、 Do not place a trampling platform in the fence
- 10、 Do not tie rope to plates and other dangerous goods。
- 11、 Part of the door lock faces out。
- 12、 Check if there are any broken or loose parts before use. If there is any damage, do not use
- 13、 Do not wash with water, wipe with a wet towel

Warning: Assembly this products is for adults only.