

ASSEMBLY INSTRUCTION

Thank you for your purchase. Please follow the instructions below for correct assembly.




STEP1




Connect part①, part③ and part④ together, secure by using 4x bolt&nut (A).

STEP2




Secure back panel part② with 4x bolt&nut (A). Attach roof part⑥, secure by using 6x screw(B) at back.

STEP3



Note: Please pay attention to (L) and (R) marked on left hinge and right hinge.

STEP4



Insect floor part 5 from left as shown.

RETURN / DAMAGE CLAIM INSTRUCTIONS

1. **DO NOT** discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: sales@tsbliving.co.nz

Christchurch Branch: customersupport@tsbliving.co.nz

Wellington Branch: wellington@tsbliving.co.nz