



---

**Dellonda Premium Pre-Lit 5ft/150cm,  
6ft/180cm, 7ft/210cm Hinged Xmas Tree  
LED's & PE/PVC Tips**



**Models DH80, DH81, DH82**

Thank you for purchasing a Dellonda product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

## Important Information

Please read these instructions carefully and note any safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.



Refer to  
instructions



Indoor use  
only





Warning:  
Keep away from  
naked flames

### • ELECTRICAL SAFETY

- **WARNING!** It is the user's responsibility to check the following:
  - Check all electrical equipment and appliances to ensure that they are safe before using. Inspect power supply leads, plugs and all electrical connections for wear and damage. Dellonda recommend that an **RCD** (Residual Current Device) is used with all electrical. You may obtain an RCD by contacting your local domestic stockist. If the product is used in the course of business duties, it must be maintained in a safe condition and routinely PAT (Portable Appliance Test) tested.
- **Electrical safety information:** It is important that the following information is read and understood.
- Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that they are secure.
- **Important:** Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating in these instructions.
- **DO NOT** pull or carry the appliance by the power cable.
- **DO NOT** pull the plug from the socket by the cable.
- **DO NOT** use worn or damaged cables, plugs or connectors.
- Ensure that any faulty item is repaired or replaced immediately by a qualified electrician.

- If the cable or plug becomes damaged during use, switch off the electricity supply and remove from use. Ensure that repairs are carried out by a qualified electrician.
- Replace a damaged plug with a **BS1363/A 13 amp 3 pin plug**. If in doubt contact a qualified electrician.



- Class **II** products are wired with live (brown) and neutral (blue) only are marked with the Class **II** symbol; 
- A) Connect the **BROWN** live wire to the live terminal 'L'.
- B) Connect the **BLUE** neutral wire to the neutral terminal 'N'.
- C) After wiring, check that there are no bare wires and ensure that all wires have been correctly connected.
- **DO NOT** connect either wire to the earth terminal.
- Ensure that the cable outer sheath extends inside the cable restraint and that the restraint is tight.
- Dellonda recommend that repairs are carried out by a qualified electrician.

- **GENERAL SAFETY**
- **WARNING:** Ensure the supply cord is not trapped or damaged.
- **WARNING: DO NOT** locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- This appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; holiday homes, hotels and other residential settings; and catering and similar non-retail applications.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of knowledge and experience if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **WARNING!** Keep item away from naked flames and other heat sources.
- Mount on firm, level and slip-free surface.
- Load tree decorations uniformly to ensure stability.
- **DO NOT** overload branches or force branch sections down.
- **DO NOT** leave young children or pets alone with the tree.
- Always remove from the power supply before moving, adjusting or cleaning the tree.
- **INTRODUCTION**
- This realistic Dellonda Christmas tree is perfect for a little extra glamour. Pre-Lit with warm white **LED** lights to save the hassle and arguments of untangling the never ending knot of lights! Our Xmas trees are specially designed to include very realistic pine branches using **PE** tips. We then use **PVC** construction for the trunk to make the tree look naturally strong, full and bushy. Our trees are tested to and comply with **EN71-2** Flammability Clause 4.1. This includes the required tests concerning the flammability of a product. Made up of **PE/PVC** branch tips to give a natural and realistic look and feel. Hinged branches make this Christmas tree easy to assemble and store away. Includes strong sturdy metal base, which folds away for easy storage. Tree suitable for indoor use only! Made from fire retardant materials.


---

## • SPECIFICATION

	DH80	DH81	DH82
Height	150cm (5ft)	180cm (6ft)	210cm (7ft)
Width	889mm (35")	1092mm (43")	1245mm (49")
Tip Style	PE/PVC Mix	PE/PVC Mix	PE/PVC Mix
No. Of Tips	772	1000+	1000+
Tip Width	5.7cm (2.25")	5.7cm (2.25")	5.7cm (2.25")
No of LED Lights	190	270	350
Construction	Hinged	Hinged	Hinged
Colour	Green	Green	Green
Metal Stand size	407mm (16")	457mm (18")	508mm (20")
Power supply	230v	230v	230v
Power	6W	6W	6W

## • ASSEMBLY

- Unpack tree sections and check condition of all parts. If in doubt, **DO NOT** use.
- Unpack metal stand arrangement and open out to form a 90° cross. Engage first few threads of locking screw into tapped hole in stand tube.
- Assemble tree sections into the base, starting with the largest, lowermost section (fig.1).
- Locate square spigot on stem into hole in stand tube. Tighten locking screw to fix tree section in place and to lock the stand in cross form.
- Locate upper section into lower section using the square spigot (fig.1).
- Arrange branches to achieve desired effects by gently arranging, separating and straightening as appropriate.
- Once the tree is assembled connect the **LED** light sections with the marked in line plugs A-A, press fully together as shown in fig. 2.
- Screw the threaded collar over the plug joint to secure in place.
- When storing the tree, after removing any decorations, unscrew the locking screw at the base and separate the sections. Fold back branches to the stem
- Fold and close the stand and place, along with tree sections and locking screw in original packing.



## Environment Protection, Waste Electrical and Waste Electronic Equipment Regulations (WEEE)

Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of its useful life, please dispose of in an environmentally friendly way. Drain any fluids (if applicable) into approved containers, in accordance with local waste regulations. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. No liability is accepted for incorrect use of this product. Guarantee is 12 months from purchase date, proof of which is required for any claim.

## Dellonda Limited

Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757575



support@dellonda.co.uk



www.dellonda.co.uk