

## How to activate your IColor SmartCUT Software using the IColor ProRIP or TransferRIP dongle

The IColor Digital Transfer Printer owner is now able to install and associate its IColor SmartCUT Software license with either the IColor ProRIP or TransferRIP USB dongle.

If you have purchased the IColor SmartCUT software after your initial equipment purchase, the following steps are required to activate your software:

- 1) Please download and install the IColor SmartCUT software from the IColor website: [www.icolorprint.com/support/](http://www.icolorprint.com/support/)
- 2) Browse to IColor Software > IColor SmartCUT > UNINET IColor SmartCUT Software Download & Update - 64 Bit
- 3) Ensure that the RIP dongle is the only memory device currently in use in your PC. Having multiple USB dongles engaged at the same time will confuse the program.
- 4) Launch the software. The license ID will automatically present itself when the software launches. For IColor ProRIP users - THIS IS DIFFERENT FROM THE PRINTED NUMBER ON THE DONGLE ITSELF.
- 5) Upon purchase, send your sales representative the code printed on the dongle as well as a screen shot of the 'Hardware ID' listed in the software. An example is shown in the screen shot below.
- 6) Note that the TransferRIP code will be the same as etched on the dongle, but the IColor ProRIP code will not.
- 7) Your representative will then send you the license key and associated information to active your product.
- 8) Copy the license key to safe place on your PC, then click 'browse' in the SmartCUT software. Navigate to the license file and click open.
- 9) You now have a fully licensed version of IColor SmartCUT.

