




BOP SPEAKER USER MANUAL



Product Interfaces and Indicators:



Button descriptions:

 **On/Off:** Switch the device ON or OFF

← **Previous/Skip Button:** Press once to **play last song**, hold down to turn **down** volume.

→ **Previous/Skip Button:** Press once to **play next song**, hold down to turn **up** volume.

 **Mode Button:** Press to switch between Bluetooth, AUX, and Radio mode.

▶ When receiving a phone call, press once to **accept** the call, press and hold the button to **reject** the call.

Press the button once to **hang up**.

When speaker is in standby or playing mode, you can double click the button to re-dial the last person called.

Charging: The Bop Speaker is powered by an integrated rechargeable lithium battery. charge the battery as follows:

1. Plug speaker into a USB port/plug. When the LED light is red, the battery is being charged.
2. When the red indicator turns off, the speaker is fully charged.

Bluetooth Pairing:

1. Turn speaker on by using the On/Off button.
2. The speaker will say 'Bluetooth Mode' and the blue LED light will be flashing when ready to connect.
3. Switch on Bluetooth on your phone and search for device.

Product Specifications:

Bluetooth support: 2.1+EDR
Maximum RF range: 10 meters
Power supplier: DC 5V
Output power: 3w
Built-in battery: 500ma
Playing time: 2-3hours
Frequency Response: 20HZ-20KHZ
Size: 150*35*40mm
Weight: 235g
Support TF Card Slot, 3.5mm Aux in, FM



Tinc Ltd. BA13 3QS
tinc.co.uk
Made in China