FLIP CLOCK



Please read the following instructions carefully to ensure satisfactory operation of this item and retain for future reference.

OPERATION

Setting the Clock:

1) Time (Calendar):

Press button to choose either 12 or 24 hour setting. Click **SET** key to set desired time setting.

Press button to adjust the HOUR - MINUTE - MONTH - DATE - YEAR sequentially.

2) Alarm:

Flip clock to 'ALARM', press **SET** button to begin changing the clock, relevant number will blink.

Press (to adjust. Press the **SET** button and the HOUR will blink. Again, press (to adjust the hour.

Press **SET** button for the second time to begin adjusting the MINUTES. Press (A) to adjust.

Press the **SET** button for the third time to complete the setting and save. The alarm icon will appear to show that it is activated.

To shut off the alarm, press the **SET** key for the fourth time.

3) Timer:

Flip the clock to TIMER, press the **SET** button to begin adjusting the MINUTES and SECONDS.

Press the button to adjust the time.

Press the **SET** button again to activate the timer.

When the timer is working, it will atomatically stop with the product is rotated.

TECHNICAL SPECIFICATIONS

- · Clock uses x2 AAA batteries
- Batteries not included
- Replace battery cover securely

4) Temperature:

Flip the clock to TEMPERATURE. Press the button to switch between Celsius and Farenheit temperature.



