WIRELESS HEADPHONES

Wireless Technology



Please read the following instructions carefully to ensure satisfactory operation of this item and retain for future reference.

CHARGING FOR WIRELESS HEADPHONES

- •To charge your Bluetooth headphones, connect a Micro USB cable to the Micro USB charging port and connect the other end to a USB power outlet (or a 5V adapter, not included).
- The LED charging indicator will turn red, indicating that the headphones are charging properly.
- When the LED indicator switches to blue, the headphones are fully charged. (To maximize the life of the battery, do not charge for more than 3 hours.)
- For best sound performance please make sure the battery is fully charged hefore first use

OPERATING THE BLUETOOTH HEADPHONES

- 1) Turn the headphones on by holding the multi-function button 🛡 💵 for 3 seconds. The LED light indicator will begin flashing blue and red.
- 2) The headphones will enter pairing mode. Enable Bluetooth search mode on your mobile phone and search for pairing name 'Tinc Wireless Headphones' and select it. Once the headphones have been successfully connected, the LFD will flash blue
- 3) Press the call function button to answer calls and hang up.
- 4) To choose the next song, press and hold the + button.
- 5) To choose the previous song, press and hold the button.
- 6) To raise volume press the + button.
- 7) To lower volume press the button.
- 8) To turn off the headphones, hold the multi-function button 🛡 🔰 for 3 seconds. The LED light indicator will flash red and turn off.
- 9) To use headphones for a wired audio source, plug in a 3.5mm audio cable into the 'AUX in' port (AUX cable is not included). The headphones will switch from 'Bluetooth' mode to 'Auxiliary' mode. (Please not that the music controls on the headphone will not function while in 'Auxiliary' mode.)

PRODUCT SPECIFICATION

- · Bluetooth version: V4.2
- · Charging input: DC 5V
- · Charging time: 2 hours
- Playing time: Up to 2-3 hours
- · Speaker diameter: 40mm
- Impedance: 32 ♠
- · Sensitivity: 100dB + 3dB
- · Battery type: Rechargable 3.7V 200mAh Li-ion
- Frequency response: 20Hz 20 KHz
- · Bluetooth range: Up to 10 metres

FUNCTIONS

- 1) Next song / Volume up
- 2) Multifuction button: Power on / off, pause / play
- 3) Previous song / Volume down
- 4) LED indicator
- 5) 3.5mm AUX In port
- 6) Micro USB charging port
- 7) Answer / Hang up calls









