


## Steps to attach tether to Aqua Pencil and Slate

Put through hole on Aqua Pencil. Pull tip through one of the three holes to secure tether to Aqua Pencil as shown.



Steps if the lead is broken inside the Runner:

③ Spread the Endpiece so the Runner falls out. See Fig. 4. Use a small paperclip and push the broken lead out of the Runner. See Fig. 5. Push the Runner back into the Endpiece, oriented correctly. Insert the Endpiece back into the tube and turn clockwise 2-3 turns. Next, push the Endpiece into the tube until it snaps into place. Once you have removed the remaining lead, gently press in a new stick - It will push in just slightly. Then spin the Endpiece to pull the new lead into the pencil.