

## LASER TATTOO PAPER

FOR SKIN AND FLAT SURFACES

# 2-PAPER-SYSTEM

**ONLY FOR LASER PRINTERS**



### PRINT SETTINGS

- **Image Mode:** mirrored
- **Media Setting:** Multi-Purpose-Tray, 175g paper or heavier



### PREPARATION


- Hold the paper at a slight angle in the light to recognize the coated side.  
Print your design in mirror image mode onto the coated side of the A-Paper.
- Use a white toner printer if you want to transfer on dark skin or dark surfaces or, if you want to use white color in the design.

**A-PAPER**  
The printable side of the A-Paper is semi-matt.  
The non-printable side is printed with our FOREVER-Logo.


**B-PAPER – GLUE**  
The B-Paper has a matt and glossy side. The matt side is the backing paper and it will be disposed of after peeling it off from the foil.



1 Peel off a corner of the white backing paper from the B-Paper and fold it over.



2 Place the A-Paper face up on a flat surface. Now stick the exposed piece precisely on the corner of the A-Paper.



4 Use a squeegee, ruler or something similar and push the B-Paper backing paper away by rubbing over the B-Paper.  
5 Now the glue is applied and the tattoo paper is ready for transfer.



### TRANSFER

- Cut around the design as exact as possible, you can use a scissor or most cutters/plotters.
- Peel off the glossy foil.
- Position the tattoo face down on clean and dry skin.
- Soak the Tattoo with a damped sponge until wet thoroughly. Apply light pressure to the tattoo.
- It is ready to be peeled off, when it can be slid away without using much force.



### NOTE

- The tattoo has a high adhesive effect. Depending on the design and its size as well as where the tattoo is placed, the durability is about 2-4 days.
- If you wish to remove your tattoo earlier, you can simply use sticky tape / scotch tape or use skin oils and rub it off.
- If you like a more matte looking appearance, you can rub sun crème / Sun Screen carefully over your new tattoo.