

## PAROPY INKJET LIGHT PRO

# APPLICATION INSTRUCTIONS

### STEP BY STEP

#### Step 1

Feed material into inkjet printer so that the printer is printing on the printable side (white matte coated side).

#### Step 2

Design your image and and resize if necessary. Print your graphic onto the paper. Use Photo Quality / Best Quality print mode.

#### Step 3

Prepress fabric for 5 seconds.

#### Step 4

Place on fabric with image face down.

#### Step 5

Heat apply the transfer onto the fabric. Press at 350F at 20 seconds. Use heavy pressure. Do not use teflon sheets when pressing.

#### Step 6

Peel after 5 seconds to allow to cool slightly. For glossy finish peel cold.

Tip: Gently stretch your fabric by tugging on the sides after pressing. This will help soften up the transfer.

### APPLICATION

Printing Inks	Dye, Pigment, or Sublimation Inks
Print Mode	Photo Quality / Best Quality
Image	Mirror
Press Time:	20 sec.
Temperature:	350F (175C)
Pressure:	Heavy
Peel:	Warm
Wash Temp.:	Up to 105F (40C )

\*Do not use teflon sheets when pressing  
All technical information and recommendations are based on tests we have conducted.  
Users should conduct their own tests before proceeding

### NOTES

#### Recommended Fabrics

White or Light Colored  
100% cotton  
100% polyester  
Poly/cotton blends  
Polyester knits  
Polyester mesh  
Poly/foam & cotton caps  
Satin

#### Accessories Required

Computer, Inkjet Printer, Heat Press.

#### Printable side

The printable side (white matte coated side) where film peels off.

#### Pressure Settings

To ensure that the coating has properly fused with the fabric, we recommend to use maximum pressure. If this paper is applied with inadequate pressure, the transfer will not wash well.

#### Peeling

This paper is to be peeled warm. Peel seconds after pressing. Also if you have difficulties peeling the backing off the shirt, while the fabric is hot, gently tug on the sides of the shirt, the backing will "pop" right out. For glossy finish peel cold.

#### Wash Instructions

Wait 24 hours before washing. Machine wash using mild detergent. Do not use bleach or other aggressive cleaning agents. Cannot be dry cleaned. Wash Temperature cannot exceed 105F. To increase color vibrancy, it is recommended to iron the image after each launder.

#### Storage

Inkjet Light has an indefinite shelf life when stored at room temperature. Keep away from direct heat, sunlight and humidity.