
# AUTOMATIC WATCH

When a watch is first purchased or if the watch hands have stopped moving, it is a good idea to gently wind the mainspring to restart, and put energy on the mainspring. An automatic watch will only wind when the watch is on your wrist and your arm moves. This is also advisable before setting the time on your watch.

To wind an automatic watch - If your timepiece has a screw-down crown, unscrew the crown by turning the crown anti-clockwise until it turns freely without tension (For a crown without a screw-down feature, simply pull the crown out to the '0' position).




Then hand wind the mainspring by simply turning the crown clockwise. Wind 15-20 times and it will start to move naturally after shaking slightly.

This watch MUST be worn for at least 8 (Eight) hours each day to ensure it is fully wound.

#### PLEASE READ THE FOLLOWING BEFORE UNSCREWING THE CROWN

#### SCREW-DOWN CROWN

Screw-down crowns are used to ensure water resistance. Always be certain that your crown is tightly screwed down. (Position "0", "1" and "2" are NOT secured for water resistance). Do NOT unscrew your crown while you are in any environment where moisture is present.



## USING THE SCREW-DOWN CROWN

#### Do NOT pull the crown unless it is unscrewed first.



**TO UNSCREW**: Turn the crown anti-clockwise until it turns freely without tension.


Once the crown is fully unscrewed, it automatically sets itself into position "0". GENTLY pull the crown out to the other desired positions for watch setting.



**TO SCREW:** Push the crown all the way in (towards the watch) THEN begin to turn clockwise until it is tightly screwed down.

Note: Failure to securely screw down the crown after setting the watch may affect its water resistance.

# SWISS MADE 'SATELLITE' CUSTOMIZED' SELF-WINDING AUTOMATIC



## TIME SETTING

- 1. Pull out the crown to position 1.
- 2. Turn the crown to rotate the hour wheels to set the time.
- 3. Push the crown back in.