



Nib Flange Arc Affect on the Nib in Oblique Pen Holders


- = Flange
- = Original Flange Arc
- = Nib



Nib will slide into the flange easy, but because it is at the exact same arc as the flange, it will not be tight in the flange



Move the arc in the direction of the arrows to tighten the nib in the flange. I recommend this be done with Yoke Pen Co. Nib Flange Pliers to avoid damage to the flange.



By flattening the arc of the flange, the nib will now touch at three points inside the flange and will not slide out.