


Wolf Tooth Front Axle Lengths



FRONT AXLE MEASUREMENT GUIDE

This guide needs to be printed at 100% to ensure proper axle sizing.

Measure the length of your axle by aligning the axle head and using the scale provided.

Explore more product solutions at:
wolftoothcomponents.com

Follow us on:   