



PUSH/PULL FOLDING WAGON BUG NET INSTRUCTIONS

CONTENTS

(1) Rain Cover

Push Pull Wagon Not Included. Sold separately.



USE/FEATURES

Now you can use your wagon in inclement weather and keep your gear and occupants dry.

- No assembly required. Easy to install.
- Folds up compactly.
- Push handle and pull handle can both still be used.
- Full width zipper door on one side.
- Keep side door open with hook and loop patch.
- Use with wagon canopy on or off.
- Cinch snaps for snug fit.
- Access rear basket from side door.
- Can be used with or without canopy.
- Set up Bug Net on wagon and let sit in sun to remove some wrinkles.

United States Patents



US 7,748,739 S
US 7,757,637 S

US 9,145,154 B1

Europe Registered Community Design No




003423193-0001
003395656-0001

CARE

Use a damp cloth to clean. Do not use chemicals.


RAIN COVER SET-UP INSTRUCTIONS

Step 1



Release all 4 canopy rods from their retaining clips. Press button with thumb and rotate canopy rods to vertical position. Release button to lock in vertical position.

Step 2



Unclip pull handle and gently rest it on the ground. Ensure no one will trip on the handle during this step. Unfold rear basket into upward position.

Step 3



Unfasten snaps, zippers, and hook and loop strips on Bug Net before installing. Ensure all four canopy rods are correctly positioned in the 4 corners of Bug Net.

Step 4




Insert handle clip through cut out in front of Bug Net. This enables use of the Pull Handle when Bug Net is installed.

Step 5



Fasten the two hook and loop strips on both sides to the rear of the wagon.

Step 6



Fasten two rear snaps. One on each side.



PUSH/PULL FOLDING WAGON BUG NET INSTRUCTIONS



SHOWN WITHOUT CANOPY TOP INSTALLED



SHOWN WITH CANOPY TOP INSTALLED

ACCESS INSTRUCTIONS

Step 1




Unzip zippers on side door to access wagon and rear basket.

Step 2



Fold door back onto top of Bug Net.

Step 3



Secure door to top of Bug Net with hook and loop patch.

REMOVAL INSTRUCTIONS

Step 1




After use, unfasten snaps, zippers, and hook and loop strips on Bug Net. Wipe off excess water with clean dry towel and allow Bug Net to air dry until completely dry.

Step 2



Unclip pull handle and gently rest it on the ground. Ensure no one will trip on the handle during this step. Unfasten snaps, zippers, and hook and loop strips on Bug Net before removing.

Step 3



Reach hand inside and gently relieve pressure from canopy rods as you carefully lift Bug Net up and off. Store completely dry, folded or hanging, in a cool, dark location.