



## CARE

Use a damp cloth to clean. Do not use chemicals. Do not machine wash

## FABRIC REMOVAL INSTRUCTIONS

### Step 1



Begin the fabric removal process by releasing the hook and loop enclosures securing the fabric to the front of the wagon frame.

### Step 2



Next, release the hook and loop enclosure securing the fabric to the rear of the wagon frame.

### Step 3



Release the four hook and loop straps at each of the four corners of the frame.

### Step 4



Turning the wagon on its side, release the hook and loop strap on the bottom of the wagon frame.

### Step 5



The fabric can now be removed from the wagon frame by pulling the fabric down the handle of the wagon.

### Step 6



The fabric is now removed and can now be cleaned or replaced.

**TO REPLACE THE FABRIC** Simply perform the steps above in reverse order. The steel handle goes through the fabric handle.  
\*\*Remember to secure the strap on the bottom of the wagon. This is required to fold the wagon with the convenient pull tab.