

## **Solenco Wireless Mini Dehumidifier**

(Designed specifically for small space dehumidification)

# INSTRUCTION MANUAL

## **APPLICATION**

The reusable mini dehumidifier is designed for removing humidity from small spaces such as closets, cabinets, clothes drawers, storage boxes, camera carry bags, linen cupboards, grocery cupboards and other enclosed spaces. It will dehumidify up to 1M3 and it is reusable over and over again!

#### **INSTRUCTIONS**

- On using the dehumidifier for the first time, remove the unit from the cellophane wrapping and ensure the beads in the indicator window are orange in colour. This shows that the dehumidifier is ready to dehumidify.
- 2) Place the dehumidifier in an upright position and ensure that it is not covered. It is not necessary to keep the dehumidifier connected to the mains.
- 3) Inspect the indicator window on a regular basis. Once the beads turn green, this indicates that the dehumidifier is full of water. The weight will increase 120g-200g.
- 4) Remove the dehumidifier and plug it into an electrical socket with the lead provided. This is to regenerate the beads and will take about 10 to 15 hours for the beads in the indicator window to turn back to orange. Please note that the dehumidifier will warm during this process.
- 5) Do not place anything on top or over the dehumidifier while charging.
- 6) The dehumidifier should not charge for more than 24 hours.
- 7) The dehumidifier needs free flow air around it whilst charging.
- 8) Place the dehumidifier in the area that requires dehumidification.

### <u>SAFETY</u>

- 1) Do not immerse in water, do not drop and do not open.
- 2) Do not use if the dehumidifier is damaged. If any of the silica beads are spilt ensure that they are not ingested. If they are consumed, seek medical advice. Ensure the damaged unit is disposed of responsibly and safely.
- 3) This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 4) Children should be supervised to ensure that they do not play with the appliance.
- 5) If the supply is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

www.solencosa.co.za Telephone: 0861 388 878