

BIGTIMECLOCKS®



1-702 726-9030



info@bigtimeclocks.biz



www.bigtimeclocks.biz

MODEL #129

15" RED NUMERALS LED WALL CLOCK

2018 USER'S MANUAL

BUTTON A: SET / MOVE

- ENTER THE MODE OF YEAR, DATE AND TIME SETTING.
- AFTER SETTING ONE, PRESS THE BUTTON TO ACTIVATE THE FLASH OF ANOTHER ONE

BUTTON B: ADD & 12/24 HR FORMAT SWITCH

CHANGE THE PRESENT FLASHING MODE BY PRESSING UNTIL THE REQUIRED NUMBER IS REACHED. 12/24HR FORMAT SWITCH WHEN NORMAL DISPLAY.

BUTTON C: SAVE

COMPLETE SETTING AND RETURN TO THE NORMAL DISPLAY

FUNCTION EXAMPLE: 10:52AM

- STEP 1: Press the button "A", "hour" flashes, Then press the button "B", adjust the value "10AM".
- STEP 2. Press the button "A", "minute" flashes, Then press the button "B", adjust the value "52".
- STEP 3. Press the button "C", the clock works.

REMARKS: "A" "B" "C" BUTTONS ON THE REMOTE CONTROL OPERATE THE SAME WAY AS DESCRIBED ABOVE.