



FiFi 2




Key Functions


- **Body Motor** – 7 vibration modes
- **Accessory Motor** - 7 vibration modes
- **Waterproof**
- **USB Rechargeable**
- **Average use time 3 hours from a single 3 hour charge.**


Control Panel





Instructions


To switch On body – Press and Hold  for 3 seconds.

To start the Motors – Press 
Each subsequent press changes the vibration mode.

To switch On accessory – Press and Hold  for 3 seconds.

To start the Motors – Press 
Each subsequent press changes the vibration mode.

To switch Off body– Press and Hold  for 3 seconds.

To switch Off accessory– Press and Hold  for 3 seconds.