

Rock



Key Functions


- **Motor** – 7 vibration modes
- **Waterproof**
- **USB Rechargeable**
- **Average use time 3 hours from a single 3 hour charge.**


Control Panel



Instructions

To switch On – Press and Hold  for 4 seconds.

To start the Motor – Press 
Each subsequent press changes the vibration mode.

To switch Off – Press and Hold  for 4 seconds.