

Thank you for purchasing a Vokera Vision boiler from Heat IQ

- Installation must only be carried out by a certifying Gas fitter with a working knowledge of condensing boilers
- The standard NZ warranty on this appliance is from the date of purchase. you must return the commissioning/guarantee registration to activate warranty. Failure to do so will limit the period of warranty to 12 months only.
- Please ensure the Relief and condensate outlets are suitably connected to an appropriate drain point we recommend using a tundish below the appliance.
- **The heating system must be filled and flushed**

Flushing is required to remove swarf from radiators which can cause premature heat exchanger failure. We advise initial fill and flush is carried out with the boiler isolated.

Where a boiler is fitted to an existing system the system must first be power flushed. We have power flushing machines available for hire.

Inhibitor

- This condensing appliance is fitted with a high gain Alloy heat exchanger. In many parts of New Zealand there are high levels of lime scale naturally present in the water supply. For protection against corrosion and scale Inhibitor is essential.

We recommend **Systemsafe DM concentrate** at minimum...

@ 500ml to a max of 8 radiators add 50mls per radiator over.

If you are using another brand of inhibitor please verify first that it is appropriate for all metals including aluminium

Please note We are aware of an Inhibitor with a **Red** colour trace dye on the market in NZ. This product must never be used in this appliance as it is not suitable for aluminium. We advise against its use in all systems with Vokera or Beretta condensing boilers

Note also: Glycol as used in solar systems is not an inhibitor