

Eco+logic AW10/15V Heat Pumps.

Total reset / Manufacturer initialisation.

In some circumstances it may be necessary to perform a manufacturer initialisation to rectify or clear a control issue. This is not an action to take lightly before doing so you should consult the regional supplier (Heat IQ NZ)

Before you perform an initialisation you must first be sure that you have to hand, the full list of User/Service and Manufacturer default settings for the appliance.

Some parameters will not be set automatically be the initialisation action. You will have to check all the parameter's and adjust to the default those which are not as the default list.

Where there are parameters that the system requires variance from the defaults we recommend you first set all parameters including these settings to their default. Returning after to make specific changes after completing the initialization set up.

To Start Initialisation, go to the initialisation screen

Default installation Enable load default value: NO

Change NO to YES > Press the enter key. The control will display loading

The controller runs the process then switches on again automatically.

You must now go through each of the settings User/service and engineer, adjusting to the default any setting which differs from the default schedule.

Now you can re configure any parameters required for your system either by following the set up start guide or under the guidance of the supplier to re commission the appliance.