
















WARNING!
ALWAYS CONNECT MACHINE
FRAME TO GROUND AND
CHECK GROUND CONTINUITY
BEFORE OPERATION!
FAILURE TO CONNECT AND CHECK GROUND
COULD RESULT IN INJURY OR DEATH



Controls Cabinet

MDPE10

Feed Throat

Back Zone

Middle Zone

Front Zone

Front Zone

Middle Zone

Back Zone

Feed Zone

AUXILIARY SIGNAL BULKHEAD

FAN 1

FAN 2

AMX10E0013

AMX10E0010

AMX10E0012

AMX10E0014 (x4)

AMX10E0020

AMX10E0020

AMX10E0009

AMX10E0011

AMX10E0021 (x7)

AMX10E0022 (x15)

AMX10E0023

AMX10E0024