


Congratulation on the purchase of your new Brilliant 22W LED Light Kit for MASCOT DC ceiling Fan. Before first using, it is most important that you read and follow these instructions, even if you feel you are quite familiar with this type of product. Keep this document handy for future reference.

THIS FITTING MUST BE INSTALLED BY A QUALIFIED ELECTRICAL CONTRACTOR in accordance with the latest AS/NZS 3000 and relevant amendments

FOR YOUR SAFETY

- To prevent electrical shock, please ensure that POWER is DISCONNECTED before installation.
- During use the light head and/or light assembly may become hot.
- Do not install in a position where the fitting can be easily accessed by children or the infirm.
- · Do not touch any parts of the assembly with bare hands while it is 'ON'.
- Be aware of the height of your installation. Refer to 'Working at Heights' guide from your local or State Authorities.
- Any alterations or additions to building wiring must be completed by a licensed electrician or person authorised by legislation to work on the fixed wiring of any electrical installation.



SPECIFICATION:			
**Input Voltage:	36V DC	Housing Material:	Steel
Light Source:	LED Array	Dimensions:	Ø 270 mm x 80 mm
Protection:	Class I (earth connection through fan shaft)	Weight:	0.825 kg
Rated Power:	22W Max	ONLY USE this light kit with ceiling fan :	MASCOT DC CEILING FAN (22197 & 22199)
Diffuser:	Frosted Acrylic shade		

**NOTE: Light kit input voltage must come from the MASCOT Ceiling Fan receiver (Model No.: 22197SP001)




Before first using your new fitting, it is most important that you read and follow these instructions, even if you feel you are quite familiar with this type of product. Retain this document for future reference.


THIS FITTING MUST BE INSTALLED BY A QUALIFIED ELECTRICAL CONTRACTOR in accordance with the latest AS/NZS 3000 and relevant amendments

INSTALLATION

- 1) Ensure the Mains Supply is switched '**OFF**'. (Fig. 1)
- 2) Unpack the fixture carefully and place it on a flat surface. Dispose of the packaging material thoughtfully.
- 3) Turn the canopy screw cover anti-clockwise and lower it down. Loosen the screws at canopy then lower down the canopy. (Fig 2)
- 4) Carefully un-plug all the connectors at the receiver and remove the receiver from the hanging bracket. (Fig. 3)
- 5) Remove the fan from the mounting bracket. (Fig. 4).
- 6) Remove all the fan blades from the fan motor and keep it aside. (Fig. 5)
- 7) Remove the fan motor bottom cover. (Fig. 6). Locate the light plug and remove the cord anchorage. (Fig. 7)
- 8) Remove the light kit mounting screws on the metal plate. (Fig. 8)
- 9) Attach the light kit and plug in the connector first before place the screws back to secure the light kit. Ensure the light plug is secure. (Fig. 9)
- 10) Attach the diffuser to the light kit by twist and lock. Ensure it tighten and secure. (Fig. 10)
- 11) Attach the fan blade previous removed. Ensure "THIS SIDE UP" is facing upward to the ceiling. Secure and tighten all screws. (Fig. 11).
- 12) Carefully lift the fan and place back to the hanging bracket. Ensuring that the hanging ball correctly locks into place. (Fig. 12)
- 13) Replace the receiver into the hanging bracket and connect the male and female couplings, and then ensure remote control receiver and all excess wiring is retained inside the ceiling canopy. (Fig. 13)
- 14) Carefully slide the canopy up to cover the hanging bracket and ball joint, taking care not to damage any wires. Once in position, secure the canopy with the screws attached. Move the screw cover plate up to cover the screws at the canopy. (Fig. 14)







- 15) Turn on the main power. The receiver should emit a beep sound. (Fig. 15)
- 16) The light will come on after the main power is turn on.
- 17) The light is ready to use.

WARNINGS

- · Do not operate this fitting in harsh environmental conditions such as building sites.
- · Do not install it on surfaces which can move or vibrate.
- Do not immerse any part of the fitting into water or any liquid.
- · Ensure wire connections are firm.
- · Do not attempt to perform modification or change parts within the light fixture.
- · Dispose of packaging thoughtfully.

SPARE PARTS			
20W CCT LED Array	Frosted Acrylic Light Diffuser		
22201SP001	22201SP002		

ENVIRONMENTAL PROTECTION:

This electrical product should not be disposed as normal waste. Please always recycle! Check with your Local Council about your recycle options.







Warranty:

Brilliant Lighting warrants this product against defects in manufacture and workmanship for a period of 1 year from date of purchase or as specified elsewhere. For products used in non-domestic or commercial applications, Brilliant Lighting warrants this product for a period of 3 months from date of purchase. This warranty is only valid for products installed and operated within the guidelines specified by Brilliant Lighting, and within the correct operating voltage ranges as stated on the product's rating label.

Warranty does not include damage or loss arising from incorrect installation, operation or maintenance of this product, damage caused through modification, incorrect installation, service by unqualified or unauthorised personnel or lack of regular maintenance and cleaning. Proof of installation by qualified personnel may be required, e.g. Electrical Safety Certificate. Proof of purchase must be supplied with all warranty claims.

This warranty is provided in addition to any other rights and remedies of the customer under any law. In applications not intended for household, personal or domestic use, liability is limited to replacement or reimbursement of product only. Brilliant Lighting does not warranty the costs of removal or re-installation of this product or associated components.

The warranty does not cover Ripple Control noise/interference (identified by a periodic or intermittent hum). This must be addressed with your energy service provider. The warranty does not cover noises or faults due to poor installation

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.

Any claim under this warranty must be made within the specified warranty period from date of purchase of this product. To make a claim under the warranty; at your own expense take the product (with proof of purchase – receipt or similar) to the store where you purchased the product or contact Brilliant Lighting at the address below.

This warranty is given by:

Brilliant Lighting (Aust) Pty. Ltd. ABN 37 006 203 694 956 Stud Road Rowville, VIC 3178

Phone: 03 9765 2555

Email: warranty@brilliantlighting.com.au Web: www.brilliantlighting.com.au

MADE IN CHINA