



# REPLACEMENT EARSEALS

---

Replacing your headset earseals

## INSTALLATION INSTRUCTIONS

EARSEAL-F-L  
EARSEAL-F-S  
EARSEAL-GEL-XL  
EARSEAL-H28AB

v1.0 | 11/24

## Step 1

**Expose the Ear Cup:** Adjust the headset so the ear cup is more accessible.



## Step 2

**Remove the Old Ear Seal:** Simply peel off the old seal.



## Step 3

**Install the New Seal:**

- Hook the small lip of the new gel seal over the ear cup, aligning the long side to the short side.
- Begin by hooking the top of the seal over the lip of the headset. Use two fingers to hold the seal in place on one side while rotating and swinging the rest of the seal into position.
- Work your way around, pressing and hooking the seal onto the headset lip with your finger.



## Step 4

**Adjust and Secure:** Once the seal is fully attached, press it into the ear cup and rotate slightly to ensure it's straight and secure.

If you have any other questions, our team is ready to help.

**RUGGEDRADIOS.COM • (888) 541-7223 • Call Our Tech Team**