



GMRS TONE CODES

CTCSS Analog Tone Codes

This is the number you toggle to on your radio!

No.	Freq. (Hz)
1	67.0
2	71.9
3	74.4
4	77.0
5	79.7
6	82.5
7	85.4
8	88.5
9	91.5
10	94.8
11	97.4
12	100.0
13	103.5
14	107.2
15	110.9
16	114.8
17	118.8
18	123.0
19	127.3
20	131.8
21	136.5
22	141.3
23	146.2
24	151.4
25	156.7
26	162.2

No.	Freq. (Hz)
27	167.9
28	173.8
29	179.9
30	186.2
31	192.8
32	203.5
33	210.7
34	218.1
35	225.7
36	233.6
37	241.8
38	250.3
39	62.5
40	69.3
41	159.8
42	165.5
43	171.3
44	177.3
45	183.5
46	189.9
47	196.6
48	199.5
49	206.5
50	229.1
51	254.1

Codes 38-51 may not be supported by other brand GMRS radios

VISIT RUGGEDRADIOS.COM TO LEARN MORE ABOUT OUR INDUSTRY LEADING GMRS RADIOS



GMRS TONE CODES

DCS Digital Tone Codes

*This is the number
you toggle to on
your radio!*

No.	DCS (Digital) Code
1	23
2	25
3	26
4	31
5	32
6	43
7	47
8	51
9	54
10	65
11	71
12	72
13	73
14	74
15	114
16	115
17	116
18	125
19	131
20	132
21	134
22	143
23	152
24	155
25	156
26	162

No.	DCS (Digital) Code
27	165
28	172
29	174
30	205
31	223
32	226
33	243
34	244
35	245
36	251
37	261
38	263
39	265
40	271
41	306
42	311
43	315
44	331
45	343
46	346
47	351
48	364
49	365
50	371
51	411
52	412

No.	DCS (Digital) Code
53	413
54	423
55	431
56	432
57	445
58	464
59	465
60	466
61	503
62	506
63	516
64	532
65	546
66	565
67	606
68	612
69	624
70	627
71	631
72	632
73	654
74	662
75	664
76	703
77	712
78	723

No.	DCS (Digital) Code
79	731
80	732
81	734
82	743
83	754
84	36
85	53
86	122
87	145
88	212
89	225
90	246
91	252
92	255
93	266
94	274
95	325
96	332
97	356
98	446
99	452
100	454
101	455
102	462
103	523
104	526

*Codes 84-104
may not be
supported by
other brand
GMRS radios*

**VISIT RUGGEDRADIOS.COM TO LEARN MORE
ABOUT OUR INDUSTRY LEADING GMRS RADIOS**