



VARIABLE SPEED CONTROLLER WIRING DIAGRAM

P.N. MAC-VSC1

The 3-wire cable connects the Variable Speed Controller to the MAC3.2 Air Pumper. For the VSC's 2-wire power cable, power and ground should be wired directly to the battery. Do not ground pumpers to chassis or common ground.

