



BLUE SKY

OUTDOOR LIVING

OWNER'S MANUAL ROUND FIRE RINGS

FR28/FR3612/PCFR3612/FR36ELK01/
FR36FR01/FR36FRM01/FR36FRM02/FR36HC01/
FR36HRS01/ FR36SP01/FR36TRN01

Blue Sky can provide elevated ambience, quality and safety to your outdoor living space. Our products are designed to create a practical space to bring people together. Whether you're using Blue Sky products to roast s'mores in your backyard, enjoy a beach bonfire, assist at your tailgate or accompany you on a camping trip, you can rely on their durability and performance. Thank you for your purchase of this Blue Sky fire ring.

CONNECT WITH US

www.blueskyoutdoorliving.com



@blueskyoutdoorliving

Fill in the following information and retain this manual for future reference:

MODEL(S): _____

DATE OF PURCHASE: _____

PLACE OF PURCHASE: _____

RECEIPT NO: _____



FR28



FR3612/PCFR3612



FR36FR01




FR36ELK01



FR36FRM01



FR36FRM02



FR36HC01



FR36HRS01



FR36SP01



FR36TRN01

FR28 (Steel)

28" Round Fire Ring
28" Dia x 10" H
71.1 cm Dia x 25.4 cm H

FR3612 (Steel)

**PCFR3612 (Steel with
Porcelain Coated Finish)**
36" Round Fire Ring
36" Dia x 10" H
91.4 cm Dia x 25.4 cm H

FR36FR01 (Abstract Fire Design)

FR36ELK01 (Elk Design)

FR36FRM01 (Farm Design)

FR36FRM02 (Farm Design)

FR36HC01 (Honeycomb Design)

FR36HRS01 (Horse Design)

FR36SP01 (Space Design)

FR36TRN01 (Train Design)

36" Round Fire Ring with Cutout Design
36" Dia x 12" H
91.4 cm Dia x 30.5 cm H

FOR YOUR SAFETY

PLEASE READ AND UNDERSTAND ALL SAFETY RULES BEFORE ASSEMBLING AND USING THIS FIRE RING. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN A HAZARDOUS FIRE, CAUSING PROPERTY DAMAGE OR PHYSICAL INJURY.

RULES FOR SAFE OPERATION

CAUTION: FOR OUTDOOR USE ONLY. DO NOT USE INDOORS.

- For adult use only – do not allow children to use the fire ring. Keep children and pets away from the fire ring while it is in use.
- Use the fire ring on stone, dirt or sand only.
- Do not use on lawns, wooden decks, concrete or asphalt.
- Do not use under a patio roof, low hanging branches, trellis, or overhangs of any kind including covered porches.
- Do not use in windy conditions.
- Do not leave fire unattended at any time.
- Avoid using softwoods such as pine or cedar, because they are likely to throw sparks. The use of seasoned hardwood is recommended.
- Do not burn trash, leaves, paper, cardboard or plywood in fire ring.
- Do not use flammable liquids such as gasoline, alcohol, diesel fuel, kerosene or charcoal lighter to light or relight fires.
- Care should be taken to make sure all combustible material is far enough away from the fire ring to not ignite.
- Always use in accordance with all applicable local and state fire codes.
- Exercise the same precautions you would with any open fire.

- Do not wear flammable or loose clothing when tending an open fire.
- Avoid touching surfaces, as they will be extremely hot.
- Assure fire is completely extinguished before leaving fire ring.
- Any modifications to this appliance may be dangerous and are not permitted.

HELPFUL HINTS


- Do not attempt to move the fire ring once the fire is started.
- Do not place the fire ring in an area where it could be easily tripped over.
- For best results, stack firewood in a pyramid shape for burning.

PARTS LIST

UNPACK PARTS, MAKING SURE ALL PIECES ARE PRESENT BEFORE ATTEMPTING TO ASSEMBLE.

REF	QTY	DESCRIPTION
A	3	Fire Ring Sides
B	1	Fire Ring Side With Support Tube*
C	16	M6 Bolts

* For use with Swing-Away Grill #SAG24. Available only on FR28, FR3612 and PCFR3612.



ASSEMBLY

TOOLS REQUIRED


10 mm socket or wrench, rake, level

STEP 1

Decide on a location for the fire ring. Make sure the fire ring is a safe distance from all combustible materials. Using a rake, level the area if necessary and remove any dry grass or overhanging tree branches.


STEP 2

Using the sixteen M6 bolts [C] provided, assemble the four pieces of the fire ring [A & B] together to form a circle. Make sure the fire ring is level, tight and in the right position.



STEP 3

Stack firewood into fire ring and light the fire.





BLUE SKY

OUTDOOR LIVING

Manufactured by:

Quality Craft

Surrey, BC, Canada V3S 5N4

service@blueskyoutdoorliving.com

1-800-459-4409

(Monday to Friday, 8:00 am–4:30 pm, CST)

Made in China

BKOLRFR-02/19