



INSTRUCTION MANUAL

MODEL:8276


PACKAGE LIST




Casters Quantity:5




Star Base Quantity:1




Gas Lift
Quantity:1




Left Plastic Cover Set Quantity:1




Right Plastic Cover Set Quantity:1




Angle Adjusters
Quantity:2




Seat Plate
Quantity:1




Seat Cushion
Quantity:1




Back Cushion
Quantity:1




Armrests
Quantity:2




Bolts M5x8mm Quantity: 4



Bolts M8x25mm Quantity: 20




Wrench Quantity:1




Plastic Caps
Quantity: 2

ASSEMBLY INSTRUCTIONS


STEP 1: Turn the Star Base upside down, then press the Casters into the holes at the end of each base leg.




STEP 2: Turn the Star Base upright and insert the lift the center hole of the Star Base.




STEP 3: Remove All M8x25mm Bolts from the seat and back.



STEP 4: Align the seat plate to the bottom of the seat cushion, make sure that the front of the seat plate is facing the front of the seat cushion. Attach the seat plate to the seat cushion using four M8x25mm bolts, tighten all the bolts with the wrench.



STEP 5: Align the seat plate to the bottom of the seat cushion, make sure that the front of the seat plate is facing the front of the seat cushion. Attach the seat plate to the seat cushion using four M8X25mm bolts, tighten all the bolts with the wrench.




STEP 6: Turn the seat cushion upright and align the center hole of the seat plate over the lift, then push the seat cushion down onto the lift firmaly until the connection is secure.




STEP 7: Using Adjusters to attach Seat Cushion, align the adjusters over the pre-drilled holes underneath the seat cushion with M8x25mm bolts, tighten all the bolts with the wrench.

Note:Please tighten the Bolts to 50%,not 100%





STEP 8: Attach Seat Cushion and Back Cushion, align the adjusters over the pre-drilled holes underneath the back cushion with M8x25 mm bolts with the wrench.



STEP 9 : Adjust balance of the full chair, then tighten all bolts to 100% on each side of adjuster.

STEP 10: Attach the Plastic Cover on right and left side with four M5x8mm bolts,using the wrench.






Congratulations! You've assembled your chair.



INSTRUCTIONS FOR USE

■ 1.Seat Height:Paddle-shaped lever on the right side



To raise

while taking your weight off chair lift lever up.

To lower

while seated, lift lever up.

*At the proper height, your feet should rest flat on the floor.

■ 2.Tilt Tension: Long stem under the seat cushion with knob



To increase tension:


while seated, turn knob forward (toward+sign).

To decrease tension: while seated, turn knob backward (toward-sign).

^{*}set the tilt tension to control the resistance you feel when leaning back.

INSTRUCTIONS FOR USE

■ 3. Operating the tilt lockout.





To let your chair tilt back, pull the control handle out.



To stop your chair from tilting, sit forward, then push the control handle in.

*At the proper height, your feet should rest flat on the floor.

■ 4.3D-Function Armrest



- ① Up and Down.
- (2) Forward and Backward.
- 3 Left and Right.

INSTRUCTIONS FOR USE

5.Backrest Recline



Pull the lever FULLY and lean back slowly until desired angle is achieved, then slowly return the lever to its starting position Ensure the lever locks back in place.

SAFETY AND MAINTENANCE

- Do not stand on the chair, Do Not use the chair as stepladder.
- Use this product for seating one person at a time.
- Do not use the chair unless all bolts and screws are firmly secured.
- Avoid contact with sharp objects to prevent puncturing the fabric.
- Every 6 months, check all bolts and screws to ensure they are tight.
- To clean, spot clean only using a damp towel and mild cleaner, first test on a small,, obscure area of fabric.
- Chair weight limit not to exceed 300 lbs.

SAFETY INFORMATION



Sit in the center of the chair, with your back to the backrest



Do not sit at the front edge of the chair



Do not stand on the chair



Do not use the chair with more than one person



Do not push the chair around when a person is sitting in it



Do not push down on the backrest when a person is reclined



Do not place all your weight on the backrest only



Do not place all your hand or fingers near the recline mechanism