

Evri by Dip Devices.
5 10 + Pod user guide.

Contents.

- Introduction.
- Basic Usage.
- Power Settings.
- Indicator Codes.
- Safety.
- Troubleshooting.
- Warranty.
- Related User Guides.

5 10 Cartridge + Refillable Pod Attachment.

Introduction.

Evri by Dip Devices is a multi-functional consumption solution. Evri features a universal battery that magnetically connects to Evri attachments. Evri attachments will evolve as consumption does, so the battery will never be obsolete! The 5 10 Cartridge/Refillable Pod Attachment (5 10/Pod) allows for 2 consumption options on one attachment! Each side of the attachment has a connection for your favorite and standard products.

Basic Usage for 5 10 cartridge.

1. Turn on device by pressing the button 5 times and connect 5 10/Pod to Evri battery with the round opening end closest to the button.
2. Screw in your 5 10 cartridge, do not overtighten cartridge.
3. Hold down the button and inhale lightly.

Basic Usage for Refillable pod.

1. Turn on device by pressing the button 5 times and connect 5 10/Pod to Evri battery with the rectangular opening end closest to the button.
2. Insert your refillable pod.
3. Hold the button down and inhale lightly.

Power Settings.

- To change the temperature setting, press the button 3 times quickly.
- Blue: low heat. Big taste with small cloud.
- Green: medium heat. Medium taste and medium cloud.
- Red: high heat. Low taste and big cloud.

Indicator Codes.

- While in use: solid color indicating current power setting.
- When attachment connected incorrectly or not present: 3 white flashes.

- When battery is completely depleted: 3 red flashes.
- When attachment connected correctly: indicator light will flash once, either:
 - Green: 51 to 100% battery remaining.
 - Yellow: 21 to 50% battery remaining.
 - Red: 0 to 20% battery remaining.

Safety.

- Read the following safety instructions before using Evri.
- Do not use Evri while charging.
- Only use this device with legal, safe, and natural concentrates.
- Do not expose Evri attachment to water or other liquids.
- Be sure to turn Evri off (with 5 quick button clicks) when you are done using it.
- Improper use, changes, or modifications to Evri could cause damage to the device or cause physical harm.

Troubleshooting.

- If you're having trouble with Evri, go to EVRI.dipdevices.com, reach out at support@dipdevices.com, or call 844-922-8273.

Warranty.

- Battery warranty covers manufacturing issues for 90 days.
- Attachments are consumable items and will only be replaced if they are not working out of the box.
- Please refer to our FAQ section for more information. (<https://support.dipdevices.com>).

Related User Guides.

- Evri Battery User Guide.
- Evri Vapor Tip Attachment User Guide.