

Evri by Dip Devices.
Vapor Tip user guide.

Contents.

- Introduction.
- Basic Usage.
- Power Settings.
- Indicator Codes.
- Safety.
- Troubleshooting.
- Warranty.
- Related User Guides.

Evri Vapor Tip Attachment.
Introduction.

Evri by Dip Devices is a multi-functional consumption solution. Evri features a universal battery that magnetically connects to Evri attachments. Evri attachments will evolve as consumption does, so the battery will never be obsolete! The Vapor Tip Attachment allows consumption of concentrate directly from its container.

Basic Usage.

1. Connect Vapor Tip Attachment to Evri battery with the atomizer end closest to the button.
2. Hold down the button to power the atomizer.
3. While holding the button, lightly touch the Vapor Tip to your concentrate. Inhale very lightly.

Dip Tip: to keep the VTA clean, do not push the Vapor Tip into the concentrate.

Power Settings.

- To change the temperature setting, press the button 3 times quickly.
- Blue: low heat. Big taste with small cloud.
- Green: medium heat. Medium taste and medium cloud.
- Red: high heat. Low taste and big cloud.

Indicator Codes.

- While in use: solid color indicating current power setting.
- When attachment connected incorrectly or not present: 3 white flashes.
- When battery is completely depleted: 3 red flashes.
- When attachment connected correctly: indicator light will flash once, either:
 - Green: 51 to 100% battery remaining.
 - Yellow: 21 to 50% battery remaining.
 - Red: 0 to 20% battery remaining.

Safety.

- Read the following safety instructions before using Evri.
- The Vapor Tip Attachment gets hot! Do not touch it while using the product or for at least three minutes after use.
- Do not use Evri while charging.
- Only use this vaporizer with legal, safe, and natural concentrates.
- Never touch the Vapor Tip Attachment to anything other than concentrate, especially individuals, flammable surfaces, or your concentrate container!
- Do not expose Evri attachment to water or other liquids.
- Be sure to turn Evri off (with 5 quick button clicks) when you are done using it.
- Improper use, changes, or modifications to Evri could cause damage to the device or cause physical harm.

Troubleshooting.

- If you're having trouble with Evri, go to EVRI.dipdevices.com, reach out at support@dipdevices.com, or call 844-922-8273.

Warranty.

- Battery warranty covers manufacturing issues for 90 days.
- Attachments are consumable items and will only be replaced if they are not working out of the box.
- Please refer to our FAQ section for more information. (<https://support.dipdevices.com>).

Related User Guides.

- Evri Battery User Guide.
- Evri 5 10 + Pod Attachment User Guide.