

Exit buttons



WEL3761S

Touchless exit button, IP67, flying leads, dual LED colour, door stay open time selectable: 2 or 10sec. **W70 x H115 x D26mm.**



WES2451

Piezo exit button, aluminium case, no moving parts, dual LED colour, IP67, door stay open time selectable: 2 or 10sec, architrave plate. **W30 x H75 x D23mm.**



WEL3761P

Touchless exit button, plastic white, IP67, flying leads, dual LED colour, door stay open time selectable: 2 or 10sec. **W70 x H115 x D26mm.**



WEL2440

Heavy duty, vandal and weather resistant exit button, IP65, all metal, large mushroom head (40mm). **W70 x H115 x D30mm.**



WEL2261

Stainless steel touchless exit button, IP65, dual LED colour, sensing range and door stay open time adjustable, dual LED colour selectable. **W70 x H115 x D28mm.**



WES2440

Heavy duty, vandal and weather resistant exit button, IP65, all metal, large mushroom head (40mm), architrave plate. **W30 x H75 x D30mm.**



WES2261

Stainless steel touchless exit button, IP65, dual LED colour, sensing range and door stay open time adjustable, dual LED colour selectable, architrave plate. **W30 x H75 x D28mm.**



WEL1911

WEL1911R (LED red)
WEL1911B (LED blue)

Stainless steel exit button, illum, green, IP65, fly leads. **W70 x H115 x D32mm.**



WEL2451

Piezo exit button, aluminium case, no moving parts, dual LED colour, IP67, door stay open time selectable: 2 or 10sec. **W70 x H115 x D23mm.**



WES1911

WES1911R (LED red)
WES1911B (LED blue)

Stainless steel exit button, illum, green, IP65, fly leads. **W30 x H75 x D32mm.**