## **Rywire Race Relay harness**

5 green - Fan relay

## 12 position Deutsch (DASH)connector (optional) 1 yellow - reverse 2 green/red - ELD (electronic load detector) 3 orange/blue - EXTRA 4 yellow/green - H20 temperature 5 green/orange - MIL (mailfunction indication lamp) 6 Yellow/red - low oil light 7 orange - EXTRA 8 blue/white - VSS (speed sensor) 9 blue - tach 10 white/blue - charge warning light 11 green/black - reverse light 12 brown/white - SCS (service check signal light) 4 position Deutsch connector 1 Red wire Fuel -Pump This wire needs to be run to the (+) side of the fuel pump. 2 Red wire Fan -This wire needs to be wired to the (+) side of the fan. 3 Red wire Spare -This wire needs to be wired to the (+) side of the aux (pump, motor, etc). 4 Red wire Spare switch -This wire needs to be wired to the (+) side of the aux (Light, etc). 12 position Deutsch (switch) connector 1 Red - Constant power 2 yellow/black - Ignition switch power 3 white/black - Starter switch 4 green/yellow - Fuel pump relay

6 blue/orange - spare relay switch
7 black - ground
8 red - constant power
9 red - switch
10 X
11 X

Battery (+) needs to go to the battery via a 4awg wire.