



Unit 3a Eden Business Park  
Dunns Close  
Nuneaton  
Warwickshire  
CV11 4NE

t: 02476 586 845  
e: info@xtra-lite.com

xtralite is a trading name of Trinity Xtras Ltd a Company  
registered in England No 4325172

One Year Limited Warranty  
Made in China  
For further product information visit  
[www.xtra-lite.com](http://www.xtra-lite.com)



NiteSafe™  
Maxi



Instruction Manual  
Model: XL20704

Please read these instructions carefully before connecting  
or using the appliance. Keep for future reference.

## Important Information

When using electrical appliances, in order to reduce the risk of fire, electric shock, and/or injury to persons, basic safety precautions should always be followed.

### For your safety...

Read all instructions carefully, even if you are familiar with the appliance.

Do not use this appliance/charger if it appears to be damaged.

Do not look directly into the light source or point it into the eyes of others. This can lead to retinal damage.

Charge the light only with the charger provided.

Do not throw the charger into fire and do not expose it to extreme heat. The charger could explode or burst.

Do not attempt to alter or manipulate the charger in any way. Doing this increases the exposure to danger significantly.

This appliance is not watertight and is unsuitable for use in damp environments.

This is not a toy. Close attention is necessary when used near children.

Do not use with a damaged outlet.

Do not handle charger with wet hands.

Do not immerse the appliance or charger in water or any other liquid.

Do not attempt to use the charger with any other product.

Only plug the charger into a standard electrical outlet. Not to be used with extension cords.

Do not operate with a damaged charger or if the appliance has malfunctioned or been damaged in any manner.

Do not allow children to play with the packaging materials.

### Nightlight Mode:

Keep the handheld light plugged into the charging base, the 6-LED front light will automatically turn on at night when the slide switch is set to Auto-Hi or Auto-Lo mode. When in the 'ON' position the front light will activate permanently (even during power failure). When set in the 'OFF' position the nightlight will not activate but power failure mode will still be available.

### Power Failure Mode:

Super bright 10-LED light automatically turns on during power failure. (Except when the slide switch is set in the ON position).

### Torch & Work Light Mode:

10-LED torch on top and 6-LED work light on the front.  
4 mode press button to activate Top 10-LEDs HI/LO/Flasher/OFF  
Set switch to ON to use front Work Light.

### Induction charging methods Rechargeable Li-ion 3.7v/500mAh battery

### Save these instructions

## Features of your NiteSafe™ Maxi

### MUST BE CHARGED FOR 24 HOURS BEFORE INITIAL USE

- Automatically turns on when the power goes out
- Torch simply slides in and out of charging base
- Induction charging technology
- Rechargeable Lithium-ion battery
- Batteries and LEDs never need to be replaced, and LEDs are always cool to the touch
- Modern design
- Lightweight and durable
- Torch with 10 super bright LEDs - 15 Lumens on power failure and 60 Lumens on Hi
- Front light with 6 super bright LEDs - 15 Lumens
- Charge lasts up to 12 hours on Lo and 3 hours on Hi
- Front work light last 5 hours
- Torch 4 position push button hi/lo/flasher/off
- Nightlight 4 position slider - on/off/auto-Lo/auto-Hi
- The 6 LED nightlight automatically turns on when darkness is detected
- 10 LED torch spread: 40m

