



Unit 3a Eden Business Park
Dunns Close
Nuneaton
Warwickshire
CV11 4NE

t: 02476 586 845
e: info@xtra-lite.com

xtralite is a trading name of Trinity Xtras Ltd a Company
registered in England No 4325172

One Year Limited Warranty
Made in China
For further product information visit
www.xtra-lite.com



NiteSafe™ Motion Detector



Instruction Manual

Model: XL20718

Please read these instructions carefully before connecting
or using the appliance. Keep for future reference.

Important Information

When using electrical appliances, in order to reduce the risk of fire, electric shock, and/or injury to persons, basic safety precautions should always be followed.

For your safety...

Read all instructions carefully, even if you are familiar with the appliance.

Do not use this appliance/charger if it appears to be damaged

Do not look directly into the light source or point it into the eyes of others. This can lead to retinal damage.

This appliance is not watertight and is unsuitable for use in damp environments.

This is not a toy. Close attention is necessary when used near children.

Do not immerse the appliance in water or any other liquid.

Do not operate if the appliance has malfunctioned or been damaged in any manner.

Do not allow children to play with the packaging materials.

Save these instructions

Features of your NiteSafe™

Motion Detector

- The light is activated when the motion sensor detects movement up to 2 metres away
- The light stays on for 30 seconds after motion is detected
- On/Off switch to allow manual control of the light
- LED Light
- Requires 3 x AAA batteries (not included)
- Twist and lock battery compartment for easy battery replacement
- Included double sided adhesive tape
- Place in dark cupboard or area with not much light

