


PARTS DIAGRAM AND LIST



Please visit our website www.UniqueAppliances.com to view a PDF version of the schematics which will allow you to zoom in and out.

PARTS DIAGRAM AND LIST

Item #	Description	Part #
1	Backsplash Back Cover Plate for UGP-24CR On/Off all colours	UGP-CY99101
2	Backsplash + Logo Black for UGP-24CR B	UGP-QJG05009
	Backsplash + Logo White for UGP-24CR W	UGP-QJG05008
	Backsplash + Logo Light Green for UGP-24CR LG	UGP-QJG05007
	Backsplash + Logo Turquoise for UGP-24CR T	UGP-QJG05010
3	Left Logo Wing for UGP-24CR all colours	UGP-CY99110
4	Classic Retro Logo for UGP-24CR all colours	UGP-CY99109
5	Right Logo Wing for UGP-24CR all colours	UGP-CY99111
6	Cast Iron Grate Set (with Dimplets) for UGP-24G/24/24CR	UGP-DWWJ01019-1
7	Backsplash Fixed Plate for UGP-24G/24/24CR	UGP-CY14516
8	Small Burner UGP-24CR all colours	UGP-QJG05020
9	Dual Burner (3 Orifices) UGP-24CR OF1	UGP-QJG00027
10	Medium Burner UGP-24 all colours	UGP-QJG05021
11	Backsplash Mount Plate UGP-24CR	UGP-CY14515-1
12	Cooking panel (Stove Top) White for UGP-24CR W	UGP-WSJ07027-W
	Cooking panel (Stove Top) Black for UGP-24CR B/LG/T	UGP-WSJ07027-B
13	Right rear gas pipe	UGP-DWWJ01312
	Right front gas pipe	UGP-DWWJ01313
	Left rear gas pipe	UGP-DWWJ01314
	Left front gas pipe	UGP-DWWJ01315
	Oven bottom gas pipe	UGP-DWWJ01316
14	Main gas pipe	UGP-DWWJ01311
15	Cooking Panel (Stove Top) Stop Plate for 20/24/24CR ON1/OF1	UGP-DCY14226
16	Thermostat Valve for 24G/24CR OF1	UGP-DWWJ01114-3
17	Gas valve 0.45	UGP-DPJ99170
	Gas valve 0.55	UGP-DPJ99171
	Gas valve 0.68	UGP-DPJ99172
18	Control Panel Black for UGP-24CR OF1 B	UGP-SYJ00099-B
	Control Panel White for UGP-24CR OF1 W	UGP-SYJ00099-W
	Control Panel Light Green for UGP-24CR OF1 LG	UGP-SYJ00099-LG
	Control Panel Turquoise for UGP-24CR OF1 T	UGP-SYJ00099-T
19	Knob Bezel for UGP-24CR all colours	UGP-WSJ04003
20	Knob White for UGP-24CR/30CR W	UGP-QJG05018
20	Knob Black for UGP-24/30CR B;LG;LB;T;R..	UGP-QJG05019
23	Bellow for UGP-30G/20/24/24CR ON1/OF1 Ranges	UGP-DWWJ01002
24	Smoke diffuser A for UGP-24/30CR	UGP-CY14239
25	Smoke diffuser B for UGP-24/30CR	UGP-CY14240
26	Upper Interior Liner for UGP-24CR OF1	UGP-WSJ13258
27	Oven Rack for UGP-24G/24CR OF1	UGP-DWWJ01319
28	Oven Floor for UGP-24G/24CR OF1	UGP-DWSJ13267-1
29	ODS bracket	UGP-CY14572
30	Nozzle Seat for UGP-30G/20 & 24/24/30CR ON1/OF1	UGP-DPJ24070
31	Oven Flame Spreader for UGP-20G/24G/30G/20 & 24CR ON1/OF1	UGP-DCY14248
32	Bottom Burner for UGP-24G/20 & 24/24CR ON1/OF1	UGP-DWWJ01317
33	ODS Assembly for UGP-24CR OF1	UGP-RDO00002
34	Broiler pan Grease Cover for UGP-24G/30G/24CR/30CR Ranges	UGP-DWSJ13269
35	Broiler Pan for UGP-24G/30G/24CR/30CR Range	UGP-DWSJ13268
36	Broiler Pan Holder for UGP-24G/24CR OF1	UGP-DWWJ01320
37	Liner bottom panel for UGP-24CR OF1	UGP-WSJ13259
38	Feet Fasten Beam (Left) for 20/24/30/24/24CR/30CR ON1/OF1	UGP-DCY14237
39	Feet Fasten Beam (Right) for 20/24/30/24/24CR/30CR ON1/OF1	UGP-DCY14238
40	Adjustable Feet for UGP-24G/24CR/30CR/30G/20/24/24CR/30CR ON1/OF1	UGP-DWWJ01010

PARTS DIAGRAM AND LIST (continued)

Item #	Description	Part #
41	Bottom Decorative (Kick Plate) Panel For UGP-24CR ON1/OF1 White	UGP-WSJ07031-W
	Bottom Decorative (Kick Plate) Panel For UGP-24CR ON1/OF1 Light Green	UGP-WSJ07031-LG
	Bottom Decorative (Kick Plate) Panel Robin Egg Blue For UGP-24CR ON1/OF1 RB	UGP-WSJ07031-RB
	Bottom Decorative (Kick Plate) Panel For UGP-24CR ON1/OF1 Black	UGP-WSJ07031-B
	Bottom Decorative (Kick Plate) Panel For UGP-24CR ON1/OF1 Turquoise	UGP-WSJ07031-T
42	Battery Container for UGP-30G/24/30CR Ranges	UGP-DWWS90026-1
43	Broiler door assy white for UGP-24CR OF1 W	UGP-QJG00116
	Broiler door assy black for UGP-24CR OF1 B	UGP-QJG00117
	Broiler door assy light green for UGP-24CR OF1 LG	UGP-QJG00118
	Broiler door assy Turquoise for UGP-24CR OF1 T	UGP-QJG00119
45	Broiler/Drawer Decorative Plate for UGP-24CR ON1/OF1 all colours	UGP-CYJ00046
47	Broiler Door Hinge for UGP-20/24/30/24/30CR OF1 Ranges	UGP-DWWJ01017
48	Broiler Seal (Gasket) for UGP-24G/24/24CR ON1/OF1	UGP-DWWJ01018-1
49	Magnet for UGP-24/30CR ON1/OF1	UGP-DWJ9945-4
50	Kick Plate Panel Support for UGP-20G/24/30CR	UGP-DCY14266
51	Hinge Base for UGP-24/30CR ON1/OF1	UGP-DWWJ01345-1
52	Thermostat Clip for 20/24/24/30CR	UGP-DCY14249
53	Interior Liner Back Board For UGP-24CR OF1	UGP-WSJ13257
54	Pulse Igniter for UGP-20G/24G/30G/24CR/30CR OF1 Ranges	UGP-DXQJ9977-1
55	Interior Back Board Support Bracket for UGP-24CR OF1	UGP-CYJ00615
56	Gas Regulator for UGP-20G/24G/30G/24CR/30CR OF1 & 24/24/30CR ON1	UGP-DPJ24060
57	Gas Regulator Fixed part for 20/24/24/24CR/30CR	UGP-DCY14271
58	Liner-Heat Insulated Fiber (back) for UGP-30G/24CR OF1 Ranges	UGP-DPJ99005
59	Back Panel Fixed Support for 20 & 24/24/24CR/30CR ON1/OF1	UGP-DCY14250
60	Back Panel for UGP-24CR OF1	UGP-CY14292-1
61	Oven/Drawer/Broiler Handle ASSY Black for UGP-24CR ON1/OF1 B	UGP-QJG05012
	Oven/Drawer/Broiler Handle ASSY Light Green for UGP-24CR ON1/OF1 LG	UGP-QJG05011
	Oven/Drawer /BroilerHandle ASSY Turquoise for UGP-24CR ON1/OF1 T	UGP-QJG05014
	Oven/Drawer/Broiler Handle ASSY White for UGP-24CR ON1/OF1 W	UGP-QJG05013
62	Oven/Drawer/Broiler Handle Base (Left&Right) for UGP-24CR/30CR ON1/OF1	UGP-CY99112
63	Oven Door Panel White for UGP-24CR ON1/OF1 W	UGP-WSJ07024-W
	Oven Door Panel Turquoise for UGP-24CR ON1/OF1 T	UGP-WSJ07024-T
	Oven Door Panel Robin Egg Blue for UGP-24CR ON1/OF1 RB	UGP-WSJ07024-RB
	Oven Door Panel Light Green for UGP-24CR ON1/OF1 LG	UGP-WSJ07024-LG
	Oven Door Panel Black for UGP-24CR ON1/OF1 B	UGP-WSJ07024-B
64	Oven Door Upper Decorative Strip (S/S) for UGP-24CR ON1/OF1	UGP-CYJ00029
65	Oven Door Heat-Insulated Fiber for 24/24CR ON1/OF1	UGP-DPJ99006-1
66	Oven Door Hinge Assembly for UGP-24CR/30CR ON1/OF1	UGP-DWWJ01016-2
67	Oven Door assy white for UGP-24CR OF1 W	UGP-QJG06020-2
	Oven Door assy black for UGP-24CR OF1 B	UGP-QJG00121
	Oven Door assy light green for UGP-24CR OF1 LG	UGP-QJG00122
	Oven Door assy turquoise for UGP-24CR OF1 T	UGP-QJG00123
69	Oven Door Glass for UGP-24G OF1/24/24CR ON1/OF1	UGP-DQT01003-1
71	Oven Seal (Gasket) for UGP-24G/24/24CR ON1/OF1	UGP-DWWJ01014-1
72	N/A	
73	Liner Heat-Insulated Fiber (Front) for 24 ON1/OF1	UGP-DPJ99003-1
74	Burner Fixed Board for 24/24CR ON1/OF1	UGP-DCY14531
75	Left Side Panel White (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00122-W
	Left Side Panel Turquoise (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00122-T
	Left Side Panel Robin Egg Blue (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00122-RB
	Left Side Panel Light Green (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00122-LG
	Left Side Panel Black (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00122-B
76	Oven Interior Left Side Panel for UGP-24CR OF1	UGP-WSJ13241

Item #	Description	Part #
77	Oven Rack Fixed Part for 20/24/24/30CR ON1/OF1	UGP-DCY14270
78	Oven Rack Support for UGP-20G/24G/20 & 24/30CR OF1/ON1	UGP-DWWJ01011-1
79	Oven Interior Right Side Panel for UGP-24CR OF1	UGP-WSJ13242
80	Right Side Panel White (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00123-W
	Right Side Panel Turquoise (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00123-T
	Right Side Panel Robin Egg Blue (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00123-RB
	Right Side Panel Light Green (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00123-LG
	Right Side Panel Black (New 2021) for UGP20G-24G & 30G/20 & 24CR ON1/OF1	UGP-PSJ00123-B
	LPG Orifice kit for UGP-24CR OF1	UGP-QJG00114
	NG Orifice kit for UGP-24CR OF1	UGP-QJG00112