

PARTS LIST

BC2300RS

CONTENTS


| | |
|--------------------------------|---------|
| 1. MAIN BODY | 1 ~ 2 |
| 2. GEARCASE | 3 ~ 4 |
| 3. ENGINE | 5 ~ 8 |
| 4. CARBURETOR, FUEL TANK | 9 ~ 10 |
| 5. ACCESSORIES | 11 ~ 12 |

2009. 10.




P/N 522908

1. BC2300RS
MAIN BODY



| Ref. No. | Part No. | Part Name | Q'ty | Remarks |
|----------|----------|-----------------------|------|------------|
| 1-1 | 363674 | BC2300RS | 1 | |
| 1-2 | 817002 | Bolt | 4 | M5x20 |
| 1-3 | 221473 | Clutch Case Ass'y | 1 | Incl.4-6 |
| 1-4 | 221474 | Clutch Case | 1 | |
| 1-5 | 016405 | Bearing | 1 | #6200ZZ |
| 1-6 | 013825 | Snap Ring | 1 | #30 |
| 1-7 | 096042 | Bolt | 1 | M5x30 |
| 1-8 | 223252 | Driveshaft Tube | 1 | |
| 1-9 | 221524 | Driveshaft Ass'y | 1 | |
| 1-10 | 229091 | Clutch Drum | 1 | |
| 1-11 | 223153 | Throttle Trigger | 1 | |
| 1-12 | 054691 | Hanging Bracket Ass'y | 1 | Incl.13 |
| 1-13 | 089738 | Bolt | 1 | M5x15 |
| 1-14 | 229041 | Label | 1 | BC2300RS |
| 1-15 | 221501 | Label | 1 | Warning |
| 1-16 | 221502 | Label | 1 | Caution |
| 1-17 | 225698 | Loop Handle Ass'y | 1 | Incl.18-20 |
| 1-18 | 225699 | Loop Handle | 1 | |
| 1-19 | 081027 | Nut | 4 | M5 |
| 1-20 | 222142 | Screw | 4 | M5x28 |
| 1-21 | 220533 | Hanging Strap Ass'y | 1 | |
| 1-22 | 096042 | Bolt | 2 | M5x30 |
| 1-23 | 231000 | Safety Cover | 1 | |
| 1-24 | 225962 | Bracket | 1 | |
| 1-25 | 225963 | Threaded Bracket | 1 | |
| 1-26 | 222898 | String Cutter Ass'y | 1 | Incl.27-29 |
| 1-27 | 081027 | Nut | 2 | M5 |
| 1-28 | 222900 | String Cutter | 1 | |
| 1-29 | 092548 | Bolt | 2 | M5x15 |

2. BC2300RS
GEARCASE




| Ref. No. | Part No. | Part Name | Q'ty | Remarks |
|----------|----------|-----------------|------|------------------------|
| 2-1 | 221657 | Gearcase Ass'y | 1 | Incl.2-16 |
| 2-2 | 220467 | Gearcase | 1 | |
| 2-3 | 089819 | Bolt | 1 | M6x8 |
| 2-4 | 219205 | Bearing | 1 | #626 |
| 2-5 | 227110 | Gear Set | 1 | |
| 2-6 | 212999 | Bearing | 1 | #6001 2RK |
| 2-7 | 055185 | Snap Ring | 1 | #28 |
| 2-8 | 140268 | Bearing | 1 | #609Z |
| 2-9 | 140269 | Snap Ring | 1 | WR9 |
| 2-10 | 140270 | Snap Ring | 1 | #24 |
| 2-11 | 092561 | Bolt | 1 | M5x25 |
| 2-12 | 212986 | Boss Adapter | 1 | |
| 2-13 | 140275 | Clamping Washer | 1 | |
| 2-14 | 215547 | Stabilizer | 1 | |
| 2-15 | 215610 | Bolt | 1 | M8x22,Counterclockwise |
| 2-16 | 219430 | Blade Shaft | 1 | |
| 2-17 | 089737 | Bolt | 1 | M5x12 |

| Ref. No. | Part No. | Part Name | Q'ty | Remarks |
|----------|----------|---------------------------|------|---------------------|
| 3-1 | 858674 | Engine | 1 | EE230/27 |
| 3-2 | 266249 | Cylinder | 1 | New gasket required |
| 3-3 | 283420 | Gasket | 1 | |
| 3-4 | 267290 | Cap Screw | 2 | M5x20 |
| 3-5 | 263772 | Insulator | 1 | New gasket required |
| 3-6 | 267049 | Gasket | 1 | |
| 3-7 | 269826 | Screw | 2 | M5x25 |
| 3-8 | 283855 | Muffler Ass'y | 1 | Incl.9-12 |
| 3-9 | 283850 | Muffler | 1 | |
| 3-10 | 268171 | Muffler Tail | 1 | |
| 3-11 | 267056 | Spark Arrester | 1 | |
| 3-12 | 265107 | Cap Screw | 2 | M4x10 |
| 3-13 | 283984 | Screw | 1 | M3x10 |
| 3-14 | 280144 | Tapping Screw | 1 | |
| 3-15 | 280341 | Crankcase | 1 | |
| 3-16 | 280488 | Bearing | 2 | PPL 6001 |
| 3-17 | 261492 | Oil Seal | 1 | ISCD12287 |
| 3-18 | 261386 | Oil Seal | 1 | ISCD12227 |
| 3-19 | 055185 | Snap Ring | 1 | #28 |
| 3-20 | 261612 | Cap Screw | 3 | M5x30 |
| 3-21 | 263569 | Piston | 1 | |
| 3-22 | 263789 | Piston Ring | 1 | |
| 3-23 | 261036 | Piston Pin | 1 | |
| 3-24 | 263957 | Bearing, Needle | 1 | KTV81112EG01 B2 |
| 3-25 | 261576 | Clip,Piston | 2 | |
| 3-26 | 267193 | Crankshaft/Conn.Rod Ass'y | 1 | |
| 3-27 | 269168 | Clutch Ass'y | 1 | Incl.28,29 |
| 3-28 | 269169 | Clutch Shoe | 2 | (2)required |
| 3-29 | 269173 | Spring, Clutch | 1 | |
| 3-30 | 269647 | Clutch Bolt | 2 | |
| 3-31 | 269175 | Washer | 2 | 6.1x15x1.6 |
| 3-32 | 261777 | Wave Washer | 2 | |
| 3-33 | 283386 | Fan Cover | 1 | |
| 3-34 | 269831 | Screw | 4 | M5x20 |
| 3-35 | 280469 | Magneto Ass'y | 1 | Incl.36-42 |
| 3-36 | 261356 | Rotor/Fan | 1 | |
| 3-37 | 280470 | Ignition Coil Ass'y | 1 | Incl.38-42 |
| 3-38 | 267401 | Coil | 1 | |
| 3-39 | 280868 | Spark Plug Wire Ass'y | 1 | Incl.40-42 |
| 3-40 | 280869 | Spark Plug Wire | 1 | |
| 3-41 | 280870 | Plug Boot | 1 | |
| 3-42 | 280871 | Connector | 1 | |
| 3-43 | 261076 | Woodruff Key | 1 | 3x10 |
| 3-44 | 261417 | Nut,Rotor | 1 | M8 |
| 3-45 | 280381 | Spacer | 2 | |





| Ref. No. | Part No. | Part Name | Q'ty | Remarks |
|----------|----------|----------------------|------|------------|
| 3-46 | 269832 | Screw | 2 | M4x25 |
| 3-47 | 262483 | Spark Plug | 1 | NGK BPMR6Y |
| 3-48 | 267492 | Lead | 1 | 130L |
| 3-49 | 282880 | Wire, Lead | 1 | |
| 3-50 | 266264 | Cap Screw | 2 | M5x50 |
| 3-51 | 264588 | Clamp | 1 | |
| 3-52 | 282404 | Recoil Starter Ass'y | 1 | Incl.53-62 |
| 3-53 | 282405 | Recoil Ass'y | 1 | Incl.54-61 |
| 3-54 | 283411 | Reel | 1 | |
| 3-55 | 283412 | Cam Plate | 1 | |
| 3-56 | 280930 | Spring | 1 | |
| 3-57 | 280931 | Spiral Spring | 1 | |
| 3-58 | 267213 | Screw | 1 | |
| 3-59 | 280932 | Starter Rope Ass'y | 1 | Incl.60,61 |
| 3-60 | 280933 | Starter Rope | 1 | |
| 3-61 | 267219 | Starter Grip | 1 | |
| 3-62 | 280934 | Starter Pawl Ass'y | 1 | |
| 3-63 | 280489 | Screw | 2 | M4x20 |
| 3-64 | 269833 | Screw | 1 | M4x16 |
| 3-65 | 283992 | Label | 1 | BC2300RS |
| 3-66 | 280409 | Gasket | 1 | |
| 3-67 | 282926 | Top Cover | 1 | |
| 3-68 | 283983 | Hook | 1 | |
| 3-69 | 286122 | Label | 1 | MARUYAMA |
| 3-70 | 267433 | Label | 1 | 83dB |

4. BC2300RS
 CARBURETOR, FUEL TANK



| Ref. No. | Part No. | Part Name | Q'ty | Remarks |
|----------|----------|-------------------------|------|-------------|
| 4-1 | 281980 | Carburetor Ass'y | 1 | Incl.2-15 |
| 4-2 | 263739 | Pump Body | 1 | |
| 4-3 | 262991 | Purge Body | 1 | |
| 4-4 | 262992 | Cover Plate | 1 | |
| 4-5 | 261874 | Primer Bulb | 1 | |
| 4-6 | 283905 | Diaphragm, Meterring | 1 | |
| 4-7 | 262993 | Gasket | 1 | |
| 4-8 | 262994 | Diaphragm,Fuel Pump | 1 | |
| 4-9 | 282576 | Gasket | 1 | |
| 4-10 | 262120 | Main Jet | 1 | #40 |
| 4-11 | 261871 | O-Ring | 1 | |
| 4-12 | 261876 | E-Ring | 1 | |
| 4-13 | 261658 | Swivel | 1 | |
| 4-14 | 264682 | Screw | 2 | |
| 4-15 | 262996 | Screw | 4 | |
| 4-16 | 261864 | Gasket | 1 | |
| 4-17 | 284823 | Case Ass'y | 1 | Incl.18-24 |
| 4-18 | 269050 | Case Body | 1 | |
| 4-19 | 284802 | Valve | 1 | |
| 4-20 | 284803 | Lever | 1 | |
| 4-21 | 269032 | Screw | 1 | |
| 4-22 | 081028 | Nut | 1 | M5 |
| 4-23 | 269051 | Sleeve | 2 | |
| 4-24 | 284816 | Washer | 1 | 6.4x11x0.15 |
| 4-25 | 281777 | Screw | 2 | M5x55 |
| 4-26 | 283772 | Cleaner Cover | 1 | |
| 4-27 | 281438 | Knob | 1 | |
| 4-28 | 280020 | Swivel Ring | 1 | |
| 4-29 | 285728 | Fuel Tank Ass'y | 1 | Incl.30-40 |
| 4-30 | 285664 | Fuel Tank | 1 | |
| 4-31 | 281564 | Fuel Tank Cap Ass'y | 1 | Incl.32 |
| 4-32 | 269377 | Gasket | 1 | |
| 4-33 | 261696 | Breather Ass'y | 1 | |
| 4-34 | 265752 | Fuel Pipe Pick-up Ass'y | 1 | Incl.35-40 |
| 4-35 | 264031 | Fuel Pipe Ass'y | 1 | Incl.36-38 |
| 4-36 | 261115 | Grommet | 1 | |
| 4-37 | 261690 | Fuel Pipe | 1 | 160L |
| 4-38 | 263038 | Return Pipe | 1 | 3x6x85L |
| 4-39 | 264653 | Filter Ass'y | 1 | |
| 4-40 | 261117 | Clip | 1 | |
| 4-41 | 261117 | Clip | 1 | |
| 4-42 | 285704 | Stand | 1 | |
| 4-43 | 284042 | Screw | 2 | M5x20 |
| 4-44 | 284043 | Screw | 1 | M5x25 |
| 4-45 | 284075 | Washer | 2 | 9x16xT0.6 |
| 4-46 | 269030 | Element | 1 | |

5. BC2300RS
ACCESSORIES



| Ref. No. | Part No. | Part Name | Q'ty | Remarks |
|----------|----------|---------------------|------|-----------|
| 5-1 | 210418 | Box Spanner | 1 | 13x19x(+) |
| 5-2 | 022865 | Double-ended Wrench | 1 | 8x10 |
| 5-3 | 210181 | Lever Handle | 1 | 3.5x170L |
| 5-4 | 231424 | Instruction Manual | 1 | |