

PARTS LIST

BC5020H-RS

CONTENTS


1. MAIN BODY	1 ~ 2
2. GEARCASE	3 ~ 4
3. ENGINE	5 ~ 8
4. CARBURETOR, FUEL TANK	9 ~ 12
5. ACCESSORIES	13 ~ 14

2009. 10.




P/N 522913

1. BC5020H-RS
MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	363679	BC5020H-RS	1	
1-2	228329	Clutch Case Ass'y	1	Incl.3-10
1-3	227729	Bearing Case	1	
1-4	140474	Bearing	2	#6202ZZ
1-5	012380	Snap Ring	1	#35
1-6	217045	Buffer (A)	1	
1-7	217046	Buffer (B)	1	
1-8	217047	Washer	1	
1-9	092033	Screw	4	M5x15
1-10	227728	Driveshaft Tube Adapter	1	
1-11	092556	Bolt	1	M6x30
1-12	211203	Clutch Drum	1	
1-13	217897	Driveshaft Ass'y	1	
1-14	217900	Driveshaft Tube	1	
1-15	217850	Hanging Bracket Ass'y	1	Incl.16
1-16	092548	Bolt	1	M5x15
1-17	217638	Bracket Ass'y	1	Incl.18,19
1-18	092554	Bolt	4	M6x25
1-19	092556	Bolt	2	M6x30
1-20	228755	Label	1	BC5020H-RS
1-21	221501	Label	1	Warning
1-22	221502	Label	1	Caution
1-23	228398	Handle Ass'y-Left	1	Incl.24,25
1-24	228399	Handle (A)	1	
1-25	226512	Grip	1	
1-26	229074	Handle Ass'y-Right	1	Incl.27,28
1-27	228401	Handle (B)	1	
1-28	229005	Throttle Trigger	1	
1-29	231041	Safety Cover Ass'y	1	Incl.30-32
1-30	223179	Bracket	1	
1-31	223180	Threaded Bracket	1	
1-32	092555	Bolt	2	M6x30
1-33	230789	String Cutter Ass'y	1	Incl.34-36
1-34	230747	String Cutter	1	
1-35	817002	Bolt	1	M5x20
1-36	228325	Nut	1	
1-37	231033	Cover Extention	1	
1-38	092552	Bolt	4	M6x20
1-39	219161	Wire Guide	2	
1-40	219612	Hanging Strap Ass'y	1	

2. BC5020H-RS
GEARCASE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	219645	Gearcase Ass'y	1	Incl.2-19
2-2	219646	Gearcase	1	
2-3	089101	Bolt	1	M8x10
2-4	092556	Bolt	1	M6x30
2-5	210560	Bearing	1	#609
2-6	227102	Gear Set	1	
2-7	217057	Blade Shaft	1	
2-8	022009	Bearing	1	#6002
2-9	016732	Snap Ring	1	#32
2-10	212394	Collar	1	15x22x8L
2-11	211818	Oil Seal	1	D22 32 6
2-12	215610	Bolt	1	M8x22,Counterclockwise
2-13	014490	Bearing	1	#6000
2-14	106933	Bearing	1	#6000Z
2-15	014210	Snap Ring	1	#10
2-16	054676	Snap Ring	1	#26
2-17	217060	Boss Adapter	1	
2-18	217061	Clamping Washer	1	
2-19	210308	Stabilizer	1	
2-20	089747	Bolt	1	M6x12

3. BC5020H-RS ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	858678	Engine	1	NE500/29
3-2	283076	Cylinder	1	New gasket required
3-3	282259	Gasket	1	
3-4	261612	Cap Screw	4	M5x30
3-5	282261	Insulator	1	New gasket required
3-6	282262	Gasket	1	
3-7	267290	Cap Screw	2	M5x20
3-8	283875	Muffler Ass'y	1	Incl.9-11
3-9	262395	Spark Arrester	1	
3-10	284052	Washer	1	M3
3-11	089530	Tapping Screw	1	M3x10
3-12	282274	Top Cover	1	
3-13	262556	Knob	1	
3-14	282277	Crankcase	1	
3-15	262658	Bearing	2	#6202C3
3-16	262660	Oil Seal	1	TC15357
3-17	262565	Oil Seal	1	ISCD15257
3-18	012380	Snap Ring	1	#35
3-19	261612	Cap Screw	4	M5x30
3-20	283078	Piston	1	
3-21	282941	Piston Ring	2	(2)Required
3-22	262749	Piston Pin	1	
3-23	262659	Bearing,Needle	1	KTV111414EG01B2
3-24	262479	Clip,Piston Pin	2	
3-25	283038	Crankshaft/Conn.Rod Ass'y	1	
3-26	282743	Clutch Ass'y	1	Incl.27,28
3-27	282624	Clutch Shoe	2	(2)required
3-28	263617	Spring,Clutch	1	2.3-44.8L
3-29	283671	Cap Screw	2	M8x1.25
3-30	262683	Washer	2	8x22x1.2
3-31	262682	Wave Washer	2	
3-32	282285	Fan Cover	1	
3-33	261250	Cap Screw	4	M5x20
3-34	282287	Magneto Ass'y	1	Incl.35-42
3-35	282288	Rotor/Fan	1	
3-36	282289	Ignition Coil Ass'y	1	Incl.37-42
3-37	267572	Coil	1	
3-38	282290	Spark Plug Wire Ass'y	1	Incl.39-41
3-39	282292	Plug Boot	1	
3-40	261075	Connector	1	
3-41	282291	Spark Plug Wire	1	
3-42	261072	Cap	1	
3-43	261076	Woodruff Key	1	3x10
3-44	262731	Nut,Rotor	1	M10
3-45	280381	Spacer	2	

3. BC5020H-RS ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	283669	Cap Screw	2	M4x25
3-47	262483	Spark Plug	1	NGK BPMR6Y
3-48	281172	Grommet	1	
3-49	267492	Lead	2	130L
3-50	264588	Clamp	1	
3-51	282294	Recoil Starter Ass'y	1	Incl.52-71
3-52	282295	Starter Ass'y	1	Incl.53-66
3-53	280994	Pulley	1	
3-54	280995	Spiral Spring	1	
3-55	280996	Pawl	1	
3-56	280997	Return Spring	1	
3-57	283123	Spring Comp.	1	
3-58	280999	Plate	1	
3-59	281000	Set Screw	1	
3-60	281004	Starter Rope	1	
3-61	262633	Starter Grip	1	
3-62	262981	Cap	1	
3-63	281005	Rope Stopper	1	
3-64	281001	Pawl	2	
3-65	281002	Return Spring	2	
3-66	282622	Screw	2	
3-67	282623	Starter Pulley Ass'y	1	Incl.68-71
3-68	282282	Starter Pulley	1	
3-69	262636	Pawl	2	
3-70	262637	Return Spring	2	
3-71	262638	E-Ring	2	
3-72	261607	Cap Screw	4	M5x16
3-73	126990	Nut	1	M8
3-74	282271	Gasket	1	
3-75	266713	Cap Screw	2	M5x60
3-76	283315	Screw	1	M5x12W-12
3-77	283284	Label	1	REVERSE2/NE500
3-78	262714	Label	1	MARUYAMA
3-79	285735	Packing	4	
3-80	267433	Label	1	83dB

4. BC5020H-RS
CARBURETOR, FUEL TANK







Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	284109	Carburetor Ass'y	1	Incl.2-16 New gasket required
4-2	283124	Pump Body	1	
4-3	263726	Cover Plate	1	
4-4	283905	Diaphragm, Meterring	1	
4-5	263727	Gasket	1	
4-6	262994	Diaphragm,Fuel Pump	1	
4-7	282576	Gasket	1	
4-8	283125	Main Jet	1	
4-9	261871	O-Ring	1	
4-10	261875	Screw	2	
4-11	264677	Bracket	1	
4-12	261876	E-Ring	1	
4-13	264678	Washer	1	
4-14	261658	Swivel	1	
4-15	261657	Packing	1	
4-16	263737	Screw	4	
4-17	282299	Pump	1	
4-18	282512	Fuel Pipe	1	
4-19	282301	Gasket	1	
4-20	283086	Divider	1	
4-21	283087	Gasket	1	
4-22	282302	Case Ass'y	1	Incl.23-28
4-23	282303	Case Body	1	
4-24	282484	Sleeve	3	
4-25	282304	Valve	1	
4-26	282305	Lever	1	
4-27	269032	Screw	1	
4-28	269423	Nut	1	
4-29	262720	Cap Screw	2	M5x55
4-30	264807	Cap Screw	1	M5x16
4-31	282481	Plate	1	
4-32	282306	Element	1	
4-33	282307	Cleaner Cover	1	
4-34	281438	Knob	1	
4-35	282309	Fuel Tank Ass'y	1	Incl.36-46
4-36	282310	Fuel Tank	1	
4-37	281564	Fuel Tank Cap Ass'y	1	Incl.38
4-38	269377	Gasket	1	
4-39	282312	Fuel Pipe Ass'y	1	Incl.40-44
4-40	268065	Grommet	1	
4-41	282511	Return Pipe	1	
4-42	262649	Fuel Pipe	1	
4-43	261590	Breather	1	
4-44	261117	Clip	1	
4-45	267328	Fuel Filter Ass'y	1	

4. BC5020H-RS
CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-46	261117	Clip	1	
4-47	261117	Clip	2	
4-48	285757	Stand	1	
4-49	281714	Cap Screw	4	M5x20

5. BC5020H-RS
ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-1	210418	Box Spanner	1	13x19x(+)
5-2	022865	Double-ended Wrench	1	8x10
5-3	210181	Lever Handle	1	3.5x170L
5-4	231424	Instruction Manual	1	