



NO.	PART NO.	PART NAME	QTY.	NO.	PART NO.	PART NAME	QTY.
1	GB/T9074. 4	Screw M5×16	5	34	134F. 11-4	Below Rocker	2
2	139F-2. 11-1	Outside Cover	1	35	134F. 11-6	Jib sealing gasket	2
3	139F-2. 11-2	Filter Net one	1	36	134F-HS. 4	Cam Wheel	1
4	139F-2. 11-3	Filter Net two	1	37	134F. 11-5	Pin	1
5	134F. 12-5	Air check valve	1	38	139F-2. 10-5	Output Valve	1
6	134F. 12-4	Air check valve	1	39	134F. 5-6	Tie-in	1
7	134F. 12-6	Air check valve bracing	1	40	139F-2. 10-2	Rocker Pin	1
8	134F. 12. 2	Seperator	1	41	139F-2. 1-2	Cupreous pipe	1
9	139F-2. 11. 1	Inside Cover	1	42	139F-2. 1-1	Cylinder Cover	1
10	134F-6	Returning oil pipe	1	43			
11	134F-5	Windpipe	1	44			
12	134F. 12-11	Choke	1	45	134F. 14-2-CE	Admitting Pipe	1
13	134F. 12-2	Choke Handle	1	46	134F-16	Admitting Gasket	1
14	134F. 12-7	baffler	1	47	139F-2. 10-7	Sealed cowling	1
15	GB/T9074. 4	Screw M5×68	2	48	139F-2. 10-8	Gasket	1
16	139F-2. 9	Carburetor	1	49	139F-2-2	Cylinder Cover Gasket	1
17	134F-15	Gasket	1	50	CMR6A	Spark Plug	1
18	GB/T70. 1	Screw M5×16	10	51	139F-2-9	Plug protective casing	1
19	134F. 12-3	Gasket	1	52	GB/T9074. 4	Screw M5×10	4
20	GB/T848	gasket 5	4	53	139F-2-1	Cylinder Cover	1
21	139F-2-11	Eliminating vane	1	54	134F-HS-3	Gasket	1
22	139F-2. 10-3	Rocker	2	55	134F. 15. 1	Muffle	1
23	139F-2. 10-6	Jib	2	56	134F. 15-1	Muffle Cover	1
24	139F. 7-5	Adjust Nut	2	57	GB/T97. 1	gasket 5	1
25	134F. 11-17	Jib Seat	2	58	GB/T818	Screw M5×6	1
26	134F. 11. 1-5	Air check valve	2	59	134FQ-12	pipe clip	2
27	139F-2. 10-9	Spring Seat	2	60	GB/T70. 1	Screw M5×40	2
28	139F. 7-10	Spring	2	61	1E40F-5-12	screw pin	2
29	139F-2. 10-4	Input Valve	1	62	1E40F-5-11	gasket	2
30	134F. 11-3	Cam and gear shaft	1	63	1E40F-5-YAT. 2	Expander	1
31	GB/T9074. 4	Screw M5×16	11	64	1E36F-3	gasket B	2
32	139F-2. 10-1	Side cover	1	65	139F-2-5	Fly Wheel Cover	1
33	134F. 11-7	Side cover gasket	1	66	GB/T9074. 15	Screw M6×16-10. 9	1

NO.	PART NO.	PART NAME	QTY.	NO.	PART NO.	PART NAME	QTY.
67	1E40F-6-1	gasket	1	100			
68	GB119.2	Pin B4×8	2	101	139F-2.4-3	O ring	1
69	134F-HS.2	Parking	1	102	GB/T70.1	Screw M5×35	4
70	GB/T9074.13	Screw M4×16	2	103	134F.5-8	clip	1
71	139F-2.8	Ignition system	1	104	GB/T276	Bearing 6201-2RS/P5	1
72	1E34FL-4	Heat insulation mat	2	105	134F.4.2-1	Gear	1
73	139F-2.3-2	First Piston Ring	1	106	134F.2	Seal	1
74	139F-2.3-3	Second Piston Ring	1	107	139F-2-3	Start Reel	1
75	139F-2.3.1	Oil ring	1	108	139F-2.2	Starter	1
76	139F-2.3-1	Piston	1	109	134F-9	Plug	1
77	P40.6-4	Ring	2	110	EB-415.4.2-4	Fuel Pipe	1
78	139F-2.3-4	Piston Pin	1	111	EB-415.4.2-2	Plug	1
79	HK101412	Needle bearing	1	112	P40.12.2-3	Cleaner	1
80	GB1096	bond C3×8	1	113	139F.1.1-1	Fuel Tank Lid	1
81	139F-2.7	Seal	1	114	CG420.1.3.1-2	Gasket	1
82	139F-2-4	Check ring	1	115	EB-415.4.1.1-1	Inlet	1
83	GB/T276	6201/P5	1	116	1E32FL.6.2-2	Inside Cover	1
84	139F-2.3.3.1	Grank Shaft	1	117	1E32FL.6.2-3	End Cover	1
85	139F-2.10.1/.4-1	Cylinder Grank Case	1	118	1E32FL.6.2-4	Chain	1
86	134F-11	Dipstick	1	119	139F-2.6-1	Fuel Tank	1
87	GB/T3452.1	O ring 14×3	1	120			
88	139F-2.4-5	Reed	1	121	139F-2-12	Tank tube	3
89	GB/T308	Ball φ4	1	122			
90	134F.5-2	Board	1	123	139F-2.5	Fuel Tank Nog	1
91	134F.5-3	Board	1	124	GB/T9074.4	Screw M5×30	3
92	GB93	gasket 4	1	125	CG420.1.3.2-2	Fuel Pipe	1
93	GB70.1	Screw M4×10	1	126			
94	139F-2-10	Sump	1	127			
95	134F.12-8	O Ring	1	128			
96	134F.5-5	Ball	1	129			
97	134F.5-7	Oil pipe	1	130			
98	139F-2.4-2	Tie-in	1	131			
99	139F-2.4-4	Ball baffle	1	132			