Easy Connected verified mobile phone list

		004510100	., .	1/0.0	_			l., .	1,00
Di	ate	2015/2/28	Version	V2.0	Date		2015/2/28	Version	V2.0
New models (OS Ver.)			Total	Brands:17 Models : 90	New models (OS Ver.)			Total	Brands:17 Models : 90
No.	Brand	Туре	OS Ver.	Car multimedia system	No.	Brand	Туре	OS Ver.	Car multimedia system
1	LG	Nexus5	2.9.2	FOR WINCE	31	Samsung	SM-A5000	4.4.4	FOR WINCE
2	LG	LG-P8810	4.0.3	FOR WINCE	32	Samsung	SM-N910X	4.4.3	FOR WINCE
3	ZTE	ZTE U9180	4.3	FOR WINCE	33	Samsung	SM-N7508V	4.3	FOR WINCE
4	HTC	M85w	4.1.1	FOR WINCE	34	Samsung	SM-N9002	4.4.2	FOR WINCE
5	HTC	D516D	4.3	FOR WINCE	35	Samsung	SM-N9008S	4.3	FOR WINCE
6	Huawei	U9508	4.1.2	FOR WINCE	36	Samsung	SM-G8508S	4.4.4	FOR WINCE
7	Huawei	C199	4.4.2	FOR WINCE	37	Samsung	SM-G3509	4.1	FOR WINCE
8	Huawei	C8816	4.3	FOR WINCE	38	Samsung	SM-G7106	4.3	FOR WINCE
9	Huawei	HONOR H30-L01	4.4.2	FOR WINCE	39	Samsung	SM-G3819D	4.1	FOR WINCE
10	Huawei	P6-C00	4.2.2	FOR WINCE	40	Samsung	SM-G9008V	4.4.2	FOR WINCE
11	Huawei	A199	4.1.2	FOR WINCE	41	Samsung	SM-T321	4.4.2	FOR WINCE
12	Huawei	H01-T00	4.4.2	FOR WINCE	42	Samsung	SM-G3818	4.2.2	FOR WINCE
13	Huawei	G620S-UL00	4.4.4	FOR WINCE	43	Samsung	SM-G9006V	4.4.2	FOR WINCE
14	Huawei	G7-UL20	4.4.4	FOR WINCE	44	Samsung	SM-G5309W	4.4	FOR WINCE
15	Huawei	G6205-UL00	4.4.4	FOR WINCE	45	Samsung	SM-W2014	4.2	FOR WINCE
16	Huawei	MT7-TL10	4.4.2	FOR WINCE	46	Samsung	SCH-N719	4.3	FOR WINCE
17	Huawei	G620-L72	4.3	FOR WINCE	47	Samsung	SCH-P709	4.2	FOR WINCE
18	Huawei	PE-TL00M	4.4.2	FOR WINCE	48	Samsung	GT-193001	4.3	FOR WINCE
19	Huawei	CHE2-UL00	4.4.2	FOR WINCE	49	Samsung	GT-19500	4.4.2	FOR WINCE
20	Huawei	G750-T00	4.2.2	FOR WINCE					
21	Google	Nexus4	4.4.4	FOR WINCE					
22	Sony	LT29i	4.1.2	FOR WINCE					
23	Sony	c6603	4.4.4	FOR WINCE					
24	Lenovo	A916	4.4.4	FOR WINCE					
25	Lenovo	A690e	4.4.4	FOR WINCE					
26	Samsung	GT-S6818	4.1.2	FOR WINCE					
27	Samsung	GT-N7102	4.3	FOR WINCE					
28	Samsung	GT-I9100	4.1.2	FOR WINCE					
29	Samsung	SM-I9508	4.2.2	FOR WINCE					
30	Samsung	SM-A3000	4.4	FOR WINCE					

Thank patronage!

user manual carefully before use it and keep it well for your future reference.

Safety Warning

• Laws of some countries prohibit users from watching TV or otherprograms and

not watch videos, TV and other related operations while driving.

any responsibility for any accidents caused during reversing (backing)

performing related operations when driving. For your personal safety, please do

• The system is only for assistant function when reversing (backing) , we accept no

We have the rights not to inform in advacne if the product descriptions in this

manual have any changing.

Class 1 Laser Products

- 1, insert SD card with map into the GPS slot on the panel of device
- 2、enter into setup interface, click GPS icon and then turn to settings of navigation path the system will automatically find out all the "exe" files in the map card, and then select correct navigation path, (as shown below) press GPS on the panel or back to main UI and click GPS icon will start navigating

Map installation and parameter

Parameter: Operation System: WIN CE 6.0 Core Chinese/English version

Chipset: MSR2112

Resolution: 800X480

GPS BAUD(Baud rate): 9600bps

GPS COM: 2



Warning

- Thank you very much for purchasing and using our digital car audio-visual 1.Do not expose the unit in the damp environment to prevent from fire or electric series products! To ensure you can use this product correctly, please read this
 - 2. Any change or modification to this unit without the clear priorconsent of the authorization party may bring inconvenience to the users.
 - 3. This unit is made up of high-precision accessories, do not dismantle the device or adjust any accessories inside this device if without authorization
 - 4.Do not touch the display screen with hard objects, so as to avoid scratching the
 - 5. Please don't install this device in these places which is in the way of driver's view or effect driving
 - 6.To avoid any traffic accidents as driver's distraction, please don't operate this device when driving, if needing to operate, please park the car in a safety
 - 7. This device is fit for such cars with 12V power supply battery system of cathode ground wire, please do not install this device to 24V battery's trucks or buses.



SWC settings

- Click" icon on the main UI to enter into the setup interface
 - . Click the steering wheel to set the steering wheel
 - 2. Click the "ico to set clear
 - on the steering wheel, and meanwhile press the function which need to be set on the display, when the icon is in selected state, that's
 - 4. Repeat the steps for other buttons
 - 5 Press"OK" to confirm once finished
- 6. Any mistake or resetting, just repeat 2-5

Note:make sure "button wire" on the steering wheel connected well with "SWC" on the unit, as shown below:2 CSW wire connected with anode of steering wheel button wire, GND conneted with cathode





ind your phone in the list and click phone name to pair, also your mobile

phone will ask matching password, just input "0000" and then click "sure" will be ok. It will appear "LINK OK". If you want to cancel pairing, just find your phone in the list and press your phone nmae for 3seconds, then your phone name will disappear it will send a pairing request for every 30seconds to you mobile phone and cause

Bluetooth use method

ensure bluetoot of your mobile phone is under searchable states when seraching.

available bluetooth device will be displayed in the middle list, if too long, just click

CODE: 0000

3,Synchronous phonebook: or for icon, a small window appears, just click " 🗸 " and then pop up a phonebook synchronization request on your phone, click "OK" to complete synchronization. Phonebook synchronization finished, input first letter of contact on the keypad of screen to search (Chinese

search is the first letter of Pinyin).

4,Dial phone:click are enter into dialing interface,input phone number on the numeric keypad to call or hang u

5,Bluetooth music:click ** enter into bluetooth music interface.Pls note that open the player on the phone first when playing music, because the car DVD player cannt start phone player. Some mobile phones may installed more than one player just start any one will be ok.



The product is used for such cars with 12V battery and negative grounding

big coach etc.cars), please install the reduction voltage equipment firstly.

• To avoid short circuit of the electrical system, please firstly switch off the

negative electrode terminal's wire of the batter before installing it

very easy to cause a fire ordamage the device.

before installing this product on these cars with 24V batteries, such as truck, bus,

• Please arrange the wiring in some place where can be fixed, thus, keep it no way

the wiring in the heat source area, such as near the heater discharge outlet,

worn, thus, it will cause short-circuit between the wiring and the car body .

When replacing the blown fuse .vou must use (10A) fuse as ruled. If use high

capacity rated fuses to replace ruled fuses, or no use fuses to direct connect,

Do not let the yellow power cord go through the engine mounting hole and introduced with warehouse positions to connect the battery , otherwise, it may

damage the power line, then, it will cause short circuit between power line and

otherwise the heat source will cause the wiring insulation layer was melted or


to touch any moving parts, such as the handbrake, gear lever, etc; Do not arrange

Common Troubleshooting Guide

Fault	Reason	Solution		
	Power fuse was burnt.	Using the same insurance with main unit to replace		
No boot up.	Other factors caused the microprocessorincorrect operation	After pressing the RESET k with a small nib on the fac panel, power on again.		
After ignition starting up and power off, all settings information were missing.	The BATT of ACC ignition positive power linemade wrong connection.	Re-connect the shunting lin		
No remote control action/function	Low battery in the remote control	replace(change) the batte of the remote control.		
Poor receive stations effect	Car antenna didn't go out Poor antenna grounding.	Checking if the ANT of radio automatic antenna control , lines are not connected well, then, please re-check the antenna and the ground wire made correct connection all.		
No way to put into Optical disc	There has installed disks already in the DVD loader /mechanism.	Pop-up the disc in the un (device), then re-insert it into again.		
	Disc was scratched	Change the good disc		
Disc can't play	Optical disk's positive and negative were placed reversal(opposite)	Put the face of optical disk logo upwards and put it in the device(unit).		
	The laser head has been dirty	Using pick up head cleaning disk to clear the pick up.		
No action to switch between Language and sub-title	CD only burned a language/ sub-title	No multilingual sub-title's di Can't make switch between language and sub-title		
No image	No connect the video cables very well from main unit to TV.	Re-connect the connection line.		
Mode screen dislocation	No making touch screen calibration very well.	calibrating touch screen,press ' button for 5seconds to enter into calibration interface		
Functional disorders	Other factors caused the microprocessorincorrect operation	After pressing the resetting key of "RESET" with a small nib on the face panel(plate), to re-boot		

MCU Software upgrade Instructions

Copy MCU software(total 2 files) as below into empty SD card; insert SD card into GPS slot while off state of the device, and then it will upgrade automatically when detect the software after power on.SD card can only be removed after upgrade completely finished.Note:power off is prohibited while upgrading



ARM Software upgrade Instructions

Copy ARM softwarde(total 8 files) as below into empty SD card;insert SD card into GPS slot while off state of the device, and then it will upgrade automatically when detect the software after power on SD card can only be removed after upgrade completely finished.Note:power off is prohibited while upgrading



Car Multimedia System

DK Series User Manual



DVD software upgrade instructions

Copy DVD softerware(total 2 files) as below into empty SD card; insert SD card into GPS slot while off state of the device, and then it will upgrade automatically when detect the software after power on.SD card can only be removed after upgrade completely finished.Note:power off is prohibited while upgrading



Mirror Link Instruction

After mobile phone bluetooth linked successfully with unit, connect this unit with mobile phone with a 2.0 USB cable, it will prompt download mirror link "phonelink" APP for the first time, and then prompt installation after finished (some mobile phones may will not prompt download and install APP). APP installation finished find the developer option on the mobile phone, and then open "USB debug", the mobile phone will connect with the unit automatically (some cellphones can only access

connection by clicking USB2 icon manually). you will be able to operate any applications of the mobile phone on this unit after connected successfully; please repeat above steps for failure. Checking whether the mobile phone has installed APP, you can see whether there is "phonelink" icon on the phone UI

The notes about the full unit's connection diagram

System Features

- RAM 256MB.DDR3 @ 1600MHz

Supported media formats for DISC

WMA, SVCD, VCD and MPEG1, MPEG2, MPEG4, JPEG format discs

• Supports SD port and USB(2.0) port.

Radio functions

- + 30 storage radio stations (FM imes 18pcs, AM12 imespcs) .

Aux input, output, amplifier and other functions

• 2 +1 channel audio output • 4 channels amplifier output.

Functions and features

• MSTAR2531chipset solution, ARM Cortex-A7 core, 800MHz main frequency,

• Flash support SLC/MLC, 128MB SLC NAND FLASH

◆ Compatible with DVD-R_DVD-RW_DVD+R_DVD+RW_CD-R_CD-RW_CD-DA_MP3

Supported media formats for USB/SD

*Compatible with MP3, WMA, WAV, AST, AVI, MP4, MPEG1, MPEG2, MPEG4, JPEG, FLAC, RMVB format

- Automatic, semi-automatic and manual search, preset memory radio stations.

TV functions(optional)

Analog TV(ATV)
 Digital TV(DTV)

+AUX input * 1 rear-view camera input * 1 *two-channes' amplifier output, which can be directly speaker

• Do not connect this product's power line with other devices's power lines , otherwise, it will cause overloading to change overheating

- Please use insulation paste to wrap the leading wire of unused speaker, so as to avoid(prevent) short circuit, please ensure that the leading wire of unused speaker gets insulation, otherwise it will cause a short circuit.
- Please ensure that keep any exposed wires to get insulation, meanwhile, bundling all electric wires very well, avoiding any connection terminals to touch the metal parts of this device's body, thus, it can prevent short sircuits.
- If your car's ignition does not have ACC position , please use ignition switch key onnect ignition wire/lead onto this on/off power source
- When turning on the power source, external power amplifier control signal leads AMP. CONT outputIf this device(unit) connected an external ampl please do not connect AMP. CONT leading wire to the end of power amplifier, otherwise, it will cause electric leakage and fault.
- For this product, forbidden its loudspeaker output terminals to connect ground wire, otherwise it will burn out the amplifier. Do not use such loudspeaker system with the common ground wire and three kinds of wires styles, no permitting to connect the loudspeaker to car body. • The loudspeaker which connects this device(unit) must be high-power type, the
- minimum rated value is 50W, impedance values (resistance value) is 4Ω , please don't directly connected a several of speaker leads or impedance values (resistance value) outside of this range, otherwise, it will cause short circuit and damage the loudspeakers.